



Quick start help for the following controllers:

B1100-PP (-HC, -XC)



Quick Start Guide B1100-PP

Table of Content

SYSTEM OVERVIEW.....	3
REFERENCES.....	3
WIRING.....	4
GETTING STARTED.....	5
QUICK START CONFIGURATION.....	15
INPUT AND OUTPUT CONFIGURATION.....	15
IO MOTION CONFIGURATION.....	16
CONTACT ADDRESSES.....	17

© 2008 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation.

NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version: 1.0b / mk 16.5.2008

System Overview

This manual gives a short step by step introduction to the functionality of the B1100-PP(-HC/-XC) servo controller family.

References


Ref	Name	Source
1	Installation_Guide_B1100.pdf	www.linmot.com
2	Usermanual_LinMot-Talk1100.pdf	www.linmot.com
3	Usermanual_EasySteps_Appl_1100.pdf	www.linmot.com
4	Usermanual_MotionCtrlSW_1100.pdf	www.linmot.com

The documentation is distributed with the LinMot-Talk1100 configuration SW, which can be downloaded from the LinMot homepage for free.

For more detailed information about the functionality of the SW please refer to the manuals above:

- Installation_Guide_B1100.pdf:
data sheet, wiring and connections
- Usermanual_LinMot-Talk1100.pdf:
how to use the configuration software
- Usermanual_EasySteps_Appl_1100.pdf :
EasySteps application software description (smart control word behavior, analog parameter scaling and IO motions)
- Usermanual_MotionCtrlSW_1100.pdf:
motion controller software description (State machine, motion interface)

Wiring



Typical servo system B1100-XX-YY: Servo controller, motor and power supply.

Getting Started

Connect the motor to the controller, wire at least the motor power supply on X1 and the 24VDC logic supply on X14.


Connect your configuration PC using a 1:1 serial RS232 cable (female/female) with the servo controller X5.

Switch on the 24V logic supply.

Start the LinMot-Talk1100 software.

Login the servo controller.

Import the B1100_PP_QuickStrt_Cfg.lmc configuration file:



Start the motor wizard to configure your motor type, follow steps 1 to 9:

Motor Wizard

Step 1/9: Actuator Selection

Actuator Data File:

PS01-37x120-HP.adf

Change Actuator ...

Stator:

PS01-37x120-HP-C20

Slider:

PL01-20x600/540-HP

The slider can be identified by its length. Newer sliders have the type engraved on the surface.

Slider Mounting Direction:

Regular

The sliders are not symmetric. The value of ZP (Zero Position) depends on the mounting direction relative to the stator. Therefore the available stroke range changes with the mounting direction.

Derived Settings	Value	Comment
STATOR	PS01-37x120-HP-C20	
Article Number	0150-1252	
Stator Length	227 mm	
Stator Mass	740 g	
SLIDER	PL01-20x600/540-HP	
Article Number	0150-1510	
Slider Length	600 mm	
Slider Mass	1327 g	
MOTOR	P01-37x120-HP/400x480-C20	
Maximal Stroke (S)	480 mm	
Shortened Stroke (SS)	400 mm	
Electromagnetic Zero Position (ZP)	230 mm	
Force Constant	20.4 N/A	
Edge Force (Fb)	67 %	

Help

< Back


Next >

Finish


Cancel

Switch on the motor power supply.

The EasySteps software can be used to control the motor over digital inputs and outputs. For testing purposes, you can wire these inputs and outputs to your control panel or simply force the values from the IO panel section in the control panel of the LinMot-Talk1100 software:




Set the input X14.14 high in order to get the motor controlled. It will automatically move for homing:




After the homing sequence, the output on X14.5 goes high indicating the motor is in target position. Also the range indicator 1 output goes high (position range between –10mm and 5mm).

The range indicator 1 is configured as shown:




This output is high, if the term (Actual Position – 0) is in the range -10mm .. 5mm.

Set the input X14.15 high, so the motor moves to 20mm. This absolute motion command is configured in the EasySteps parameter section.



The output of range indicator 1 (mapped to X14.19) has been cleared. The output in target position (X14.5) may be cleared for a short time and will be set again.

Set the input X14.3 high, so motor moves to 50mm. This absolute motion command is configured in the EasySteps parameter section.



The output of range indicator 2 (mapped to X14.7) has been cleared. The output in target position (X14.5) may be cleared for a short time and will be set again.

The range indicator 2 is configured as shown:

Name	Value	Raw Data	UPID	Type	Scale	Offset	Min	Max	Default
Range Indicator 2 Minuend UPID	F4D9h (Actual Po...	62681	625Ch	Uln16	1	0	0000h	FFFFh	F4D9h
Range Indicator 2 Subtrahend UPID	3041h (Zero 32 Bit)	12363	625Dh	Uln16	1	0	0000h	FFFFh	3041h
Range Indicator 2 Low Limit Raw D...	450000 (= 45 mm)	450000	F138h	Sln132	0.0001 mm	0 mm	-2147483648	2147483647	450000
Range Indicator 2 High Limit Raw ...	510000 (= 51 mm)	510000	F13Ch	Sln132	0.0001 mm	0 mm	-2147483648	2147483647	510000

This output is high, if the term (Actual Position – 0) is in the range from 45mm to 51mm.

Quick Start Guide B1100-PP

Set the input X14.2 high, the motor moves to 0mm. This absolute motion command is configured in the EasySteps parameter section:

The screenshot shows the LinMot-Talk1100 V3.7 Build 20071206 software interface. The left sidebar shows the project tree with 'Unnamed on COM3' selected. The main window is divided into several sections:

- Control:** A list of 15 digital inputs and outputs. Inputs 0-15 are listed with their current status (0 or 1). Input 14.2 is set to 1.
- Status:** A list of 15 status bits. Bit 0 (Operation Enabled) is 1. Bit 1 (Switch On Active) is 1. Bit 2 (Enable Operation) is 1. Bit 3 (Error) is 0. Bit 4 (Voltage Enable) is 1. Bit 5 (/Quick Stop) is 1. Bit 6 (Switch On Locked) is 0. Bit 7 (Warning) is 0. Bit 8 (Event Handler Active) is 0. Bit 9 (Special Motion Active) is 0. Bit 10 (In Target Position) is 1. Bit 11 (Homed) is 1. Bit 12 (Fatal Error) is 0. Bit 13 (Motion Active) is 0. Bit 14 (Range Indicator 1) is 1. Bit 15 (Range Indicator 2) is 0.
- Monitoring:** A section showing connection status (Online), firmware status (Running), and motor status (Switched On). It also displays the motor's current position (0.55 mm) and demand position (0.00 mm).
- IO Panel:** A section showing the status of digital inputs and outputs. Inputs 14.14, 14.2, 14.15, 14.3, 14.16, and 14.4 are all set to 1. Outputs 14.17, 14.5, 14.18, 14.6, 14.19, and 14.7 are all set to 0.
- Motion Command Interface:** A section for sending motion commands. It includes a 'Command Category' dropdown (Most Commonly Used), a 'Command Type' dropdown (No Operation (0000h)), and a 'Count Nibble (Toggle Bits)' dropdown (0h). It also has a table for command data.

Set the input X14.16 high, the motor moves to 5mm. This incremental motion command is configured in the EasySteps parameter section as well.

The screenshot shows the LinMot-Talk1100 V3.7 Build 20071206 software interface. The left sidebar shows the project tree with 'Unnamed on COM3' selected. The main window is divided into several sections:

- Control:** A list of 15 digital inputs and outputs. Inputs 0-15 are listed with their current status (0 or 1). Input 14.2 is set to 1.
- Status:** A list of 15 status bits. Bit 0 (Operation Enabled) is 1. Bit 1 (Switch On Active) is 1. Bit 2 (Enable Operation) is 1. Bit 3 (Error) is 0. Bit 4 (Voltage Enable) is 1. Bit 5 (/Quick Stop) is 1. Bit 6 (Switch On Locked) is 0. Bit 7 (Warning) is 0. Bit 8 (Event Handler Active) is 0. Bit 9 (Special Motion Active) is 0. Bit 10 (In Target Position) is 1. Bit 11 (Homed) is 1. Bit 12 (Fatal Error) is 0. Bit 13 (Motion Active) is 0. Bit 14 (Range Indicator 1) is 1. Bit 15 (Range Indicator 2) is 0.
- Monitoring:** A section showing connection status (Online), firmware status (Running), and motor status (Switched On). It also displays the motor's current position (4.68 mm) and demand position (5.00 mm).
- IO Panel:** A section showing the status of digital inputs and outputs. Inputs 14.14, 14.2, 14.15, 14.3, 14.16, and 14.4 are all set to 1. Outputs 14.17, 14.5, 14.18, 14.6, 14.19, and 14.7 are all set to 0.
- Motion Command Interface:** A section for sending motion commands. It includes a 'Command Category' dropdown (Most Commonly Used), a 'Command Type' dropdown (No Operation (0000h)), and a 'Count Nibble (Toggle Bits)' dropdown (0h). It also has a table for command data.

Set the input X14.16 high, the motor moves to 10mm. This incremental motion command is configured in the EasySteps parameter section.

Control

- 0: Switch On.....1 Digital Input X14.14
- 1: Voltage Enable.....1 Forced by Parameter
- 2: /Quick Stop.....1 Forced by Parameter
- 3: Enable Operation.....1 Forced by Parameter
- 4: /Abort.....1 Forced by Parameter
- 5: /Freeze.....1 Forced by Parameter
- 6: Go To Position.....0 Interface
- 7: Error Acknowledge.....0 Interface
- 8: Jog Move +.....0 Interface
- 9: Jog Move -.....0 Interface
- 10: Special Mode.....0 Interface
- 11: Home.....0 Interface
- 12: Clearance Check.....0 Interface
- 13: Go To Initial Position.....0 Interface
- 14: Linearizing.....0 No Source Specified
- 15: Phase Search.....0 No Source Specified

Control Word: 003Fh
Override Value
Enable Manual Override

Status

- 0: Operation Enabled.....1
- 1: Switch On Active.....1
- 2: Enable Operation.....1
- 3: Error.....0
- 4: Voltage Enable.....1
- 5: /Quick Stop.....1
- 6: Switch On Locked.....0
- 7: Warning.....0
- 8: Event Handler Active.....0
- 9: Special Motion Active.....0
- 10: In Target Position.....1
- 11: Homed.....0
- 12: Fatal Error.....0
- 13: Motion Active.....0
- 14: Range Indicator 1.....0
- 15: Range Indicator 2.....0
- 0: Motor Hot Sensor.....0
- 1: Motor Short Time Overload.....0
- 2: Motor Supply Voltage Low.....0
- 3: Motor Supply Voltage High.....0
- 4: Position Lag Always.....0
- 5: Position Lag Standing.....0
- 6: Controller Hot.....0
- 7: Motor Not Homed.....0
- 8: PTC Sensor 1 Hot.....0
- 9: PTC Sensor 2 Hot.....0
- 10: RR Hot Calculated.....0
- 11: Reserved.....0
- 12: Reserved.....0
- 13: Reserved.....0
- 14: Interface Warn Flag.....0
- 15: Application Warn Flag.....0

Status Word: 0C37h
Op. Main State: 08h
Op. Sub State: C0h
Warn Word: 0000h
Logged Error Code: 0000h

Monitoring

Connection Status: Online
Firmware Status: Running
Motor Status: Switched On

Op. State: Operation Enabled

Actual Position: 9.71 mm
Demand Position: 10.00 mm
Force Factor: 93.76 %
Motor Current: 0.88 A
Logic Supply Volt.: 23.42 V
Motor Supply Volt.: 75.39 V

IO Panel

Enable Manual Override

Override Value Actual Value

- X14.14 - Input
- X14.2 - Input
- X14.15 - Input
- X14.3 - Input
- X14.16 - Input
- X14.4 - Input
- X14.17 - Output
- X14.5 - Output
- X14.18 - Output
- X14.6 - Output
- X14.19 - Output
- X14.7 - Output

Motion Command Interface

Enable Manual Override: ☐

Command Category: Most Commonly Used

Command Type: No Operation (000xh)

Count Nibble (Toggle Bits): 0h ☐ Auto Increment Count Nibble


Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	000xh: No Operation	0	0	0000h

Read Command Send Command


An incremental motion command can be used e.g. for stacking or de-stacking applications.

To change positions without using the LinMot-Talk1100 software, the EasySteps software supports the possibility of teaching positions manually over a single separate input. The following sequence has to be executed for a correct teaching:

First, select the motion, which has to be changed, by setting this output high. The motor moves to the position.



Then set the teach in input (X14.4 high), this makes the motor currentless, so the motor can be moved manually to the new position (in this example 30.03mm). Note: in vertical applications the slider can drop down due to gravitation.




When the motor is moved to the desired position, set the teach in input low, the motor is now position controlled and powered again, and the new position for the selected IO motion is stored remanently (survives a power cycle).

Quick Start Configuration


Input and Output Configuration

The inputs and outputs in the quick start example are configured as:




The input X14.4 is mapped to the control word bit switch ON. In the EasySteps configuration the additional behavior of this bit is configured as following:

- Auto home
- Error acknowledge to falling edge of the "Switch On" flag




IO Motion Configuration

The input X14.14 is mapped to the control word bit “Switch On”, for this reason no IO motion functionality is configured for this input.




On the input X14.2 no MC SW functionality is mapped, so it's free to use as IO motion input. In the quick start example the motion go to absolute position is configured. The motion parameters (target position = 0mm, max speed = 0.4m/s, acceleration = 1m/s² and deceleration = 1m/s²) are configured in the section X14.2 IO Motion Config.



On the inputs X14.15 and X14.3 are also go to absolute position commands, with target positions 20mm and 50mm configured.

On the input X14.16 'Increment Target Position' IO motion command is configured. In this case the parameter position = 5mm, means not the absolute position but the target position's increment. So on a rising edge of X14.16 the old target position is incremented by 5mm. A negative position value would decrement the target position. This kind of motion commands can be used for stacking or de-stacking applications.



On the input X14.4 the 'Teach In IO Motion' is configured. This functionality is only available on this input.

Contact Addresses

SWITZERLAND

NTI AG
Haerdlistr. 15
CH-8957 Spreitenbach

Sales and Administration: +41-(0)56-419 91 91
office@linmot.com

Tech. Support: +41-(0)56-544 71 00
support@linmot.com

Tech. Support (Skype) : skype:support.linmot

Tech. Support (Skype) : skype:support.linmot

Fax: +41-(0)56-419 91 92
Web: http://www.linmot.com/

USA

LinMot, Inc.
5750 Townline Road
Elkhorn, WI 53121

Sales and Administration: 877-546-3270
262-743-2555

Tech. Support: 877-804-0718
262-743-1284

Fax: 800-463-8708
262-723-6688

E-Mail: us-sales@linmot.com
Web: http://www.linmot-usa.com/

Please visit <http://www.linmot.com/> to find the distribution near you.

Smart solutions are...

