




**Documentation of
LinMot-Talk 1100
Configuration Software**



LinMot-Talk 1100
User Manual

© 2009 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 3.11 / December, 2009

Table of Content


1 INTRODUCTION.....	4
2 OVERVIEW.....	4
2.1 TOOL BUTTON BAR.....	5
2.2 CONTROL PANEL.....	6
2.3 MESSAGES PANEL.....	7
2.4 ERRORS PANEL.....	8
2.5 OSCILLOSCOPE.....	9
2.6 CURVES.....	10
2.7 PARAMETERS.....	11
2.8 VARIABLES.....	11
2.9 COMMAND TABLE.....	13
2.10 ACCESS CODES.....	14
3 QUICK START GUIDE.....	15
3.1 CABLING E1100.....	15
3.2 CABLING E1200.....	16
3.3 CABLING B1100.....	17
3.4 FIRMWARE DOWNLOAD.....	18
3.5 LOGIN.....	18
3.6 SCANNING CAN BUS.....	19
3.7 SCANNING ETHERNET	20
3.8 MOTOR WIZARD.....	21
3.9 CONTINUOUS CURVE MODE.....	29
3.10 DEFINING CURVES.....	30
3.11 CONTROL STATUS.....	34
3.12 OSCILLOSCOPE.....	35
3.13 CONTINUOUS TWO POINT MODE.....	37
3.14 EXPORT CONFIGURATION.....	38
3.15 IMPORT CONFIGURATION.....	39
3.16 OFFLINE CONFIGURATION.....	39
4 TROUBLE SHOOTING.....	40
4.1 SETTING ALL PARAMETERS TO DEFAULT VALUES.....	40
4.2 INTERFACE DOES NOT RUN.....	40
4.3 STOPPING FIRMWARE.....	40
5 CONTACT ADDRESSES.....	41

1 Introduction

The LinMot-Talk1100 software is a PC based tool, which helps the user in a comfortable way installing firmware on the controller, setting up the controller's configuration, defining and programming motion profiles, emulating the PLC, watching variables and reading messages and errors. The LinMot-Talk 1100 works with the controller series E1100, E1200 and B1100.

2 Overview

The following screen shot gives an overview of the different functions integrated in the LinMot-Talk 1100 software.



2.1 Tool button bar



The tool button bar is always present and consists of the following buttons (from left):

- **Show/Hide Tree** shows or hides the project tree window.
- **Up** sets the focus in the project tree to the parent of the selection.
- **Import Configuration** imports a controller's configuration.
- **Export Configuration** exports a controller's configuration. Different parts, such as parameters, variables, oscilloscope or curves, can be selected to be exported.
- **Print** prints items like curves, parameter configurations etc.
- **Install Firmware** Start the controller's firmware installation.
- **Reboot** restarts the firmware on the controller.
- **Stop** stops the firmware on the controller, used for downloading and software configuration.
- **Go Offline** logs out from actual controller.
- **Start Motor Wizard** starts the motor configuration setup wizard.
- **Show Control Panel** switches to the control panel.
- **Show Parameters** switches to the variables.
- **Show Variables** switches to the variables.
- **Show Oscilloscope** switches to the oscilloscope.
- **Show Messages** switch to the message viewer.
- **Show Errors** switches to error viewer.
- **Show Curves** switches to the curve tool.
- **Show Command Table** switches to the command table editor.
- **Show Object Inspector** displays a window in which shows help information to each selected object.

2.2 Control Panel

The Control Panel helps the user to access directly to the control and status word of the MC Software. The controller can be commanded from the PC, thus no PLC is necessary to be used for the first commissioning.

The screenshot shows the LinMot Control Panel software interface. It is divided into several sections:


- Control Word:** A list of 16 control bits (0-15) with their current states. Below the list, the Control Word is displayed as 003Fh. There are checkboxes for 'Override Value' and 'Enable Manual Override'.
- Status Word:** A list of 16 status bits (0-15) with their current states. Below the list, the Status Word is displayed as 40F6h. There are checkboxes for 'Op. Main State' and 'Op. Sub State'.
- General Monitoring:** Displays connection status (Online), firmware status (Running (INTF stopped)), and motor status (Switched Off). It includes a motor symbol and a warning icon. Below, it shows 'Op. State: Not Ready to Switch On' and 'Motor Not Homed'. It also displays actual position (0.00 mm), demand position (0.00 mm), force factor (Motor not homed), motor current (0.00 A), logic supply voltage (26.21 V), and motor supply voltage (48.13 V).
- IO Panel:** A list of 12 digital inputs (X4.12 to X4.3) and one output (X4.3 - Output). Each input has a status indicator (green or red) and a checkbox for 'Act'. There is a checkbox for 'Enable Manual Override' and a text field for 'Override Value'.
- Motion Command Interface:** Includes a checkbox for 'Enable Manual Override', a set of buttons for position offsets (-10 mm, -1 mm, +1 mm, +10 mm), a dropdown for 'Command Category' (Most Commonly Used), a dropdown for 'Command Type' (No Operation (000xh)), and a dropdown for 'Count Nibble (Toggle Bits)' (0h). There is also a checkbox for 'Auto Increment Count Nibble'. Below this is a table with columns: Name, Offs., Description, Scaled Value, Int. Value (Dec), and Int. Value (Hex). The table contains one row: Header, 0, 000xh: No Operation, 0, 0, 0000h. At the bottom are buttons for 'Read Command' and 'Send Command'.

- **Control Word** The MC software's control word can be directly written from the PC. For taking over the PC control the left check box (Enable Manual Override) must be selected. The state of each flag can be set with the right check box (Override Value). If other flags have to be altered, the override mask must be configured in the parameter tree under \Parameters\Motion Control SW\State Machine Setup\Control Word\Ctrl Word Parameter Force Mask.
- **Status Word** The status word shows the actual state of the controller's MC software status word. It is updated automatically.
- **General Monitoring** This window displays actual motor and controller information
- **IO Panel** For commissioning; the user can take control of the X4 IOs on E1100 or X14 IOs on B1100 controllers.
- **Motion Command Interface** The MC software's motion command interface can be directly accessed over this window. When enabled (Enable Manual Override switch must

be set), MC commands can be selected, parameterized and sent to the controller. Because the motion command interface is, independent of the interface running on the controller, the same, the commands can be exactly tested before programming them in the PLC.


2.3 Messages Panel

This panel reads out and shows all messages, which are logged on the controller, and displays them in chronological order. If logged in a B1100 series controller, this window does not appear, because those controllers do not support message logging.



2.4 Errors Panel


This panel reads out and shows all errors, which are logged on the controller and displays them in chronological order.



2.5 Oscilloscope

The controller's built in oscilloscope, which can record up to four channels in real time, is controlled with the oscilloscope tool.

During login the oscilloscope reads out the settings and data from the controller. If an oscilloscope shot is running or ready to read out data, an item called "Read out" will be displayed. Otherwise a default item will be generated.



The oscilloscope is controlled with the buttons




The functions are (from left):

- **Start/Abort** Start or abort an oscilloscope shot.
- **Fit View** Displays the recorded channels such as they fit best in the scope window.
- **Save Display** stores the settings for zoom, scaling and offset.
- **Recall Display** restores the settings for zoom, scaling and offset, which are previously stored with Save Display.
- **Export Data** Export data and setups of the last recorded oscilloscope shot in a csv file.
- **Oscilloscope Settings** Switch to setup mask for channels, triggers, times and modes.
- **Display Settings** is used to set scale, offset and color for the oscilloscope channels.
- **Show/Hide** Show and hide the oscilloscope channels.
- **Edit Properties:** The oscilloscope name and comment can be set individually.

2.6 Curves

With the curve tool, motor motion profiles can be easily created, joined, uploaded, downloaded and saved. NOTE: On B1100 the curve feature must be enabled with an access key.



The curve tool is divided into the edit and the download window. The edit window is used to generate, merge and modify curves with the following buttons:



- **New Curve** Starts the curve wizard, which guides through the curve generation.
- **Edit Properties** The properties of a selected curve, like name, time or stroke, can be modified.
- **Edit Curve Values** The curve points can be manually edited.
- **Join Curves** All selected curves are joined together. A wizard will be started for defining the curve properties of the joined curve.


The download window is used to manage the curves, which are stored on the controller or have to be downloaded. Modifications in this window will show up the message "Curves have changed! Please download." After pressing the download into controller button the window and the controller will be synchronized.



- **Upload Curves from Controller** All curves stored on the controller will be uploaded and displayed.
- **Download Curves to Controller** The controller's curve sector will be synchronized with the download window.
- **Auto Numerate Curves** The curve ID, which must be unique, will be set automatically.

2.7 Parameters


The controller's parameters are displayed in a tree view.



Parameters which are marked as live (L) can be altered while the controller's firmware is running, other parameters can only be changed when the software is stopped.

2.8 Variables

The controller's variables, which can be watched, are arranged in different functional groups. The MC SW overview group contains the most used variables.




The variable service is controlled with the following buttons:



- **Show/Hide Details** Additional information for each parameter, such as unique parameter ID (UPID), scaling, min/max value, can be displayed on demand.
- **Read Variable** Reads the selected variable from the controller once.
- **Write Variable** Writes the selected variable to the controller.
- **Read All Variables** Reads from the controller all variables of the section once.
- **Read All Variables Cyclically** Reads from the controller all variables of the section cyclically.

The following buttons are only used in special cases.


- **Edit Properties** The parameter properties can be displayed and changed.
- **New ... Variable** In a new generated variable section a new variable can be defined. This is a drop down menu, which supports different variable types.
- **New Bit Variable** In a new generated variable section a variable of the type bit can be defined.
- **New String Variable** In a new generated variable section a variable of the type string can be defined.
- **New Float32** In a new generated variable section a variable of the type float32 can be defined.
- **New With UPID** In a new generated variable section a variable can be added by using the UPID from the appropriate parameter.

Under “User Defined” any variables or parameters can be arranged together. Typically the variables are selected via UPID (). It is also possible to drag and drop them from the parameter or variable section.

2.9 Command Table

The controller supports the command table (CT) functionality, which means a set of up to 255 motion commands (31 commands for B1100GP and B1100VF series controllers, on B1100PP CT is not supported) can be stored in this table.

An example of is shown in the following picture:



A big variety of commands can be set in this tables, such as motion commands, conditions, sequence directives, parameter access, ... This makes the CT to very powerful functional unit. The CT entries can be accessed (executed) via digital inputs (on X6) or via interface software.

The CT tool has the following editing elements:

- **Entry ID** indicates the CT entry, which is being edited.
- **Entry Name** is a descriptive string of max. 16 characters
- **Motion Command Category** the available commands are fitted into groups for keeping a better overview
- **Motion Command Type** specifies the command to be executed in this entry.
- **Auto execute new command on next cycle** when selected, on the next cycle the entry specified under "ID of Sequenced Entry" will be executed. This gives the possibility of defining cycles, simple logical sequences.
- **ID of Sequenced Entry** defines the CT entry executed on the next cycle when "Auto execute new command on next cycle" is activated.
- **Apply** writes the edited values into the entry.
- **Upload from Controller** reads and displays the entire command table from the controller.
- **Download to Controller** writes the edited table (from the PC) to the controller.

An application example of the CT can be found in the motion control software user manual (Usermanual_MotionCtrlSW_E1100.pdf).

2.10 Access Codes

On the controller special features or customer specific applications can be protected by a software key. This means, a key must be activated by an access code, which is controller specific (pinned to the serial number). Under Controller\Set Access Code\ the following window will open:

Name	Value	Access Code
Key1	5A93h - Force Closed Loop Control	58328193h
Key2	0000h - No Key	
Key3	0000h - No Key	
Key4	0000h - No Key	

Set Key Access Code:

Name: Key2 Value (HEX): 5a92 Access Code (HEX): 583C6B91 Write

Note: The keys will not be activated on the controller until a reboot has been processed. Press the "activate" button to reboot.

Activate Close

A maximum of four keys can be set on the controller. Under Active Keys all valid installed keys are listed (key value and access code). A new key can be set by selecting the key name and defining the value and access code. With the write button, the key and access code are written to the controller. As soon as the controller has rebooted (click the Activate button) the new key will be active, if the access code fits.


Please note: Access codes are controller specific. They cannot be copied from one controller to another.

3 Quick Start Guide

This chapter helps step by step to set up a system using servo controller and the LinMot-Talk 1100 configuration software.

3.1 Cabling E1100


The following picture shows the connectors on the controller used for a first commissioning (with PC only).



- **X1** Motor Supply, use 48..72 VDC (between PWR+ and PGND).
- **X2** Motor Phases: if this connector is not present, connect the motor on X3 only.
- **X3** Motor signals: if motor has a DSUB-9 connector, connect it directly, otherwise use an adapter to DSUB-9 or wire the phase lines to X2.
- **X4** For a commissioning with the PC it is necessary to wire only the Pin1 (GND), Pin2 (+24VDC) and, if present, Pin12 save voltage enable (SVE, +24VDC).
- **X5** RS232: The cable between the LinMot controller and PC must be DSUB-9 F/F, 1:1 (X modem). If the PC has no COM port available, use the USB to RS232 converter (LinMot article number 0150-3110).

3.2 Cabling E1200


The following picture shows the connectors on the controller used for a first commissioning (with PC only).



- **X1** Motor Supply, use 48..72 VDC (between PWR+ and PGND).
- **X2** Motor Phases.
- **X3** Motor Signals. (Note: the motor phases are not present on this connector. Thus wire the motor phases in any case to X2).
- **X4** For a commissioning with the PC it is necessary to wire only the Pin1 (GND), Pin2 (+24VDC) and, if present, Pin12 save voltage enable (SVE, +24VDC).
- **X15/X16** Ethernet: Use a standard RS45 patch cable to wire to the LAN.

3.3 Cabling B1100


The following picture shows the connectors on the controller used for a first commissioning (with PC only).



- **X1** Motor Supply, use 48..72 VDC between (PWR+ and PGND).
- **X2** Motor Phases
- **X3** Motor signals: if motor has a DSUB-9 connector, connect it directly, otherwise use an adapter to DSUB-9 or wire the phase lines to X2.
- **X5** RS232: The cable between the LinMot controller and PC must be DSUB-9 F/F, 1:1 (X modem). If the PC has no COM port available, use the USB to RS232 converter (LinMot article number 0150-3110).
- **X14** For a commissioning with the PC it is necessary to wire only the Pin13 (DGND) and Pin25 (+24VDC).


3.4 Firmware Download

As the cabling is done correctly now, turn on the controller's power and start up the LinMot-Talk 1100 software. Before using the controller the first time, the firmware has to be downloaded. Therefore

press install firmware button  to start the wizard. Choose the file "Firmware_V3S11_Build20091204.sct" (or similar) and press "Open". Then the wizard will start and guide through the installation. According to the controller type, different interface and application software can be selected.

3.5 Login


When successfully finished downloading the firmware, login with \File\ Login..., then select the appropriate port and press ok. A login info window will appear showing the login progress. When logged in you will find the following window:



The Object Inspector window can be dragged away or closed. It can be reopened with F1.

3.6 Scanning CAN Bus


When one or several controllers are linked with CAN bus for configuring, it can be very helpful to scan the CAN bus for linked controllers automatically. Thus, it is not necessary to know all node IDs. Under \File\Scanning (with CANusb) a list of the present controllers will be displayed:




With just one click the LinMot-Talk1100 software will log in to all controllers.

3.7 Scanning Ethernet

When one or several controllers are linked with Ethernet for configuring, it is helpful to scan the automatically for linked controllers. Thus, it is not necessary to know all node IP addresses. Under \File\Scanning (via Ethernet) first the interface has to be selected (network link)



a list of the present controllers will be displayed:



With just one click the LinMot-Talk1100 software will log in to all controllers. The colored markings have the following meaning:



Green: The controller is ready to log in.




Grey: You are already logged into this controller.




Red: Another instance is logged into this controller (other user or other interface).


3.8 Motor Wizard

As no motor is defined, the next step is to start the motor setup wizard.

Press the button  and the following window will appear:



As we want to configure a LinMot Motor we choose “LinMot Linear Motors” and press Open.



Select the actuator type you have wired to the controller, then press Open.

The following steps will show forms including drawings and descriptive texts.

The first step is to define the stator and slider.

Motor Wizard

Step 1/9: Actuator Selection

Actuator Data File: P501-37x240.adf Change Actuator ...

Stator: P501-37x240

Slider: PL01-20x500/420

The slider can be identified by its length. Newer sliders have the type engraved on the surface.

Slider Mounting Direction: Regular

The sliders are not symmetric. The value of ZP (Zero Position) depends on the mounting direction relative to the stator. Therefore the available stroke range changes with the mounting direction.

Derived Settings	Value	Comment
MOTOR	P01-37x240/160x360	
Maximal Stroke (S)	360 mm	
Shortened Stroke (SS)	160 mm	
Electromagnetic Zero Position (ZP)	130 mm	
Force Constant	40.8 N/A	
Edge Force (Fb)	58 %	
SLIDER	P501-37x240	
Article Number	0150-1203	
Stator Length	347 mm	
Stator Mass	1385 g	
SLIDER	PL01-20x500/420	
Article Number	0150-1328	
Slider Length	500 mm	
Slider Mass	1064 g	

Navigation: Help < Back Next > Finish Cancel

The derived settings show information about the complete motor type, article numbers and the most important technical data.

The next step is to choose the flange for defining the cooling capability.

[illegible]

Longer extension cables will have an effect to the motor's phase resistance. In step 3 can be defined two cable segments.

[illegible]

The next hardware setup step is to define an external position sensor system (if present). For E1100 controllers can be chosen between none, incremental AB(Z) and analog sine/cosine 1Vpp. For B1100 controllers can be chosen between none, incremental AB(Z) and AB encoder simulation.

Step 4/9: External Position Sensor System

External Position Sensor

Type: Analog Sine/Cosine (1Vpp) ▼

Count Direction: Positive ▼

Resolution r (1/4 Period Length): 250 um

With an additional external position measuring system the positioning accuracy and the linearity can be improved. The optional position sensor has to be connected to X12 on the controller.

Derived Settings	Value	Comment

◀ | ▶

Help
< Back
Next >
Einish
Cancel

With step 5 the feed forward parameters are set up. Depending on the moving mass, additional load mass, friction and orientation. Under the derived settings the influence can be watched.

[illegible]

With the next and last step the position controller's parameters will be set up:

[illegible]

It is recommendable to start with the default soft settings, because the parameters can be changed any time later on (by restarting the motor wizard or by setting in the parameter tree directly).

With the soft parameter setting, PID values will be quite low such as the motor is low noise and the position is not controlled very stiffly.

The stiff parameter set tends to more noise and more power consumption of the motor, but the position will be controlled harder.

In both settings, the I Gain is set to zero, which means a steady-state deviation from the desired position can occur. When using the I Gain, the position controller may tend to swing.

The Noise Filter option is to reduce the noise from the position feedback sensor at standstill.

For finding the best set of PID parameters, the system has to be optimized iteratively. There is no general way of how to optimize the settings, because different goals can be achieved such as position accuracy, power minimization, noise reduction, ...

The next step is to define the homing procedure.

Motor Wizard

Step 7/9: Homing I

Home Position Search Move

Speed: 0.01 m/s

Mode: Mechanical Stop Negative Search

The motor moves in negative direction until a mechanical stop is reached. This position is assumed to be the Home Position.

Before motion commands can be executed, the motor must be homed. Depending on the selected mode, the motor searches a mechanical stop and/or an electrical switch.

Derived Settings	Value	Comment

Help < Back Next > Finish Cancel


The most frequently used homing mode is “Mechanical Stop Negative Search”. In this case the slider will move with the notch towards the stator’s front end (where no cable is). Other modes support homing on home switches, limit switches, indexer inputs or some combinations of those.

Step 8 is to define the slider home position. This is for the motor and controller the most important value. It defines at the home position, where the slider is positioned relative to the stator. This defines how far the motor can move in each direction.

Motor Wizard

Step 8/9: Homing II

Distance from Stator End to Slider End at the Home Position



Distance A mm

Distance B mm

The controller needs to know the physical position of the slider relative to the stator. Please determine either distance A or distance B when the motor stands at the Home Position (mechanical stop or switch). Hence you can move the motor manually to the Home Position. Then you can measure A or B (stator end to slider end) and enter the corresponding value. The other value is calculated by the software. If the slider end is inside the stator tube, then you have to give your entry a negative sign.

Derived Settings	Value	Comment
Slider Home Position	10 mm	Corresponds to distance A

Help < Back Next > Finish Cancel

With the last wizard step the user's coordinate system can be defined.

Motor Wizard

Step 9/9: Homing III

Definition of the Application Reference System

Home Position (HP): mm

Move to the Initial Position at the End of the Homing Procedure

Initial Position (IP): mm

You can define your application specific reference system by assigning any position value to the Home Position. All further position values are based on this system.
At the end of the homing procedure the motor moves to the Initial Position. Then it is ready to execute the motion commands. If the motor has to be homed on a mechanical stop, then the Initial Position value should differ from the Home Position.

Derived Settings	Value	Comment
Minimal Position (stroke range limit)	-70 mm	
Maximal Position (stroke range limit)	290 mm	
Distance C	20 mm	
Distance D	133 mm	

Help < Back Next > Finish Cancel

At the end, press finish. If the firmware on the controller is still running, an appropriate message will be shown. All parameters will now be written to the controller.


The motor wizard can be run several times, e.g. to setup an external sensor, to change the load setup or to change the motor type. When rerunning it, at the end will be shown a list of parameters, which will be changed.

3.9 Continuous Curve Mode


We want the motor to run a curve cyclically. (The easiest, but not so informative way to run the motor would be the VAI 2 Pos Continuous mode)

The controller is set to continuous curve mode by selecting “Continuous Curve” under \Motion Control SW\Motion Interface\Run Mode Settings\Run Mode Selection\ in the parameter tree.

NOTE: For enabling the curve feature on B1100 controllers, it is necessary to set an access key.





The second parameter to be set is to define which curve has to be run. Set the parameter “Curve ID” to 1 under \Motion Control SW\Motion Interface\Time Curve Settings\.




Before running the curve, it is advisable to define the curve we want to run.


3.10 Defining Curves

Curves can be easily defined with the curve wizard. For this example we will define two sine curve forms over a stroke of 50mm out and in with different speeds, which will be joined together.


Now, step by step: Open the curve tool by clicking the “Show Curves” button  in the tool button bar. Then press the “New Curve” button  to start the curve wizard.




As we want to define a curve in position vs. time mode we can keep the default selection and press the next button.




In this mask, we will set the curve ID to 2 (we will have the merged curve with ID 1 at the end) and as name we set e.g. “SineOut”. The end point is placed at 50mm. With “Next” the wizard will show some curve data:




The next and last mask proposes a number curve setpoints. It is advisable to accept this proposal.



With “Finish” the first curve is defined. The curve will be displayed as follows:



We will now define curve going back. So we start the curve wizard again and define under curve settings the following:




Curve Settings dialog box with the following fields:

- Curve ID (1..100): 3
- Curve Name: SineIn
- Setpoint Calculation Wizard: Sine
- Curve Length: 500 ms
- Start Point: 50 mm
- End Point: 0 mm

Buttons: < Back, Next >, Cancel

Set curve ID to 3, Curve Name to “SineIn”, Curve Length to 500ms, Start Point to 50mm and End Point to 0mm. Click twice “Next” and then “Finish”.


Now we have defined the two curve segments and will join them together. Select the two curves




LinMot-Talk 1100 - V3.6 Build 20060609 main window showing the Project tree on the left and the Edit Window on the right. The Edit Window contains a table with the following data:

Name	ID	Type	Setpoint Wizard	Length	No. of Setpoints
SineOut	2	Position vs. Time	Sine	1000 ms	501
SineIn	3	Position vs. Time	Sine	500 ms	501

Below the table is a Download Window with buttons for Upload from Controller, Download into Controller, and ID.

then press the “Join Curves” button . The curve settings mask for the joined curve appears:




Curve Settings dialog box for the joined curve with the following fields:

- Curve ID (1..100): 1
- Curve Name: SineOutIn
- Setpoint Calculation Wizard: None
- Curve Length: 1500 ms


Buttons: < Back, Next >, Cancel



We will set the curve name to “SineOutIn” and make sure the curve ID is 1.

The curve length is proposed as the sum of the curve segment times. Press “Next” and “Finish”. The curve for the continuous curve mode is now defined and has, according to the parameter settings, the curve ID 1. As we want to download the curves to the controller we select all the curves in the edit window and move them to the download window.





When double click the “SineOutIn” Curve the joined curve is shown:




Now the curves must be downloaded to the controller. Therefore press the “Show Curves” button  and then the “Download Curves into Controller” button . Then a warning comes up which has to be confirmed and the progress window will display the actions taken to download the curves.


3.11 Control Status

As we have defined now all parameters and curves, we will let the motor running. For this time, we will take over the interface control from the PC. So we are interface-independent.

Switch to the control panel with the button , then press the start button  (starting the controller's firmware) and wait until the control status panel is updated and looks the following:






Now we will fetch the control over the “Switch On” and the “Home” flags.





Now turn off and turn on again the “Switch On” flag, this is because of the auto start prevention. At this time, the motor will be powered and position controlled at the actual position. Set the “Home” flag and the motor will initialize against the inner hard stop. When the motor stands still, clear the “Home” flag and the motor will run the curve continuously.


Detailed information about the MC software's state diagram can be found in the MC software manual.


3.12 Oscilloscope

The oscilloscope is a very useful tool for tuning the motor. The LinMot Talk 1100 software has defined a default oscilloscope, which samples the actual position, demand position, position difference and demand current. When clicking on the “Show Oscilloscope” button , the focus will be set to the default oscilloscope. We could start the oscilloscope now with the start button , but it is recommended to set the recording time about 2 seconds (one curve cycle is 1.5 s). We will switch to the oscilloscope settings with .



Then press Ok and start the oscilloscope with . The recorded data on will be read out from the controller and displayed, which will look somehow like the following.

Possibly it is necessary to press button  (fit view).




Tuning the system would be started at this point. One possibility is by restarting the Motor Wizard and changing the load or control parameter, another one is to change the parameters directly in the parameter tree.


3.13 Continuous Two Point Mode

The easiest way to run the motor continuously, is to set the VAI 2 Pos Continuous mode. In this mode the motor moves between the two positions Trig Fall and Trig Rise. The time the motor waits at the two positions is defined under “VAI 2 Pos Cont Settings”.

The minimal settings for this mode are shown next. First the mode has to be set:





And then the positions have to be set under “Trig Fall Config\Position” and “Trig Rise Config\Position”:



This is all we have to configure. The speed, acceleration and deceleration can also be defined at this place in the parameter tree. The motor can now be started the same way as described under 3.11 Control Status.


3.14 Export Configuration


When the controller settings are done it is strongly recommended to save the complete configuration. This can be done under File → Export... or with by clicking on . After the file name dialog the selection of the parts to be exported will be shown:



It is recommended to export all. For a configuration recovery it is necessary to select the parameters, curves and command table. In case of a support request it is very helpful to provide the complete configuration as well (with variables, oscilloscope shots, message and error log).

3.15 Import Configuration


A configuration can be imported with File → Import... or with the button . When opening a configuration to a controller, a compatibility list of the parameter trees will be shown. Then the selection of the importable parts will be shown:



It is possible to import only some specific parts (e.g. curves or command table).

3.16 Offline Configuration

A configuration can also be opened when no controller is present. Under File → Login/Open offline...



This is a very helpful feature for supporting problems.

4 Trouble shooting

4.1 Setting all Parameters to Default Values

All parameters of a E1100 controller can be set to their default values without the use of the LinMot Talk1100. This can be done according these steps:

1. Power off the controller
2. Set the two ID switches to Ffh
3. Power on the controller, the ERROR and WARN LEDs will blink alternately.
4. Set the two ID switches to 00h
5. Wait until the WARN and EN LEDs will flash together.
6. Power off and on again.

NOTE: This feature is not supported on B1100 series controllers.

4.2 Interface does not run

If the interface software (DeviceNet, CANopen, Profibus, LinRS) does not communicate there may be several reasons:

- Specific Interface Software not installed
- Switch S3.4 "Interface" on controller's bottom side must be set to "On". (In case of LinRS, this switch must be set to off when configuring over RS232, and set to on when running the LinRS interface).
- Parameter with UPID 2008h set to disable.
- Baud Rate and Node ID selection not correctly set (Parameters and/or ID switches on controller's front).

4.3 Stopping Firmware

When the same link is used for configuration purposes and from the interface (e.g. RS232 link and LinRS interface) it may not be possible to login with the LinMot-Talk software. In some cases, it should be possible to log in, e.g. to download new firmware.

On E1100 controllers, the interface switch S3.4 can be set to off and after a power up the interface software should be deactivate and the configuration link should be free. If this does not help, or you are working with a B1100 controller, there is a script under File -> Open -> StopFirmware.sct, which keeps trying to stop the controllers firmware while it is powered on. After a power up, within the first 2 seconds the interface can be prevented from starting.

5 Contact Addresses

SWITZERLAND

NTI AG
Haerdlistr. 15
CH-8957 Spreitenbach

Sales and Administration: +41-(0)56-419 91 91
office@linmot.com

Tech. Support: +41-(0)56-544 71 00
support@linmot.com

Tech. Support (Skype) : skype:support.linmot

Fax: +41-(0)56-419 91 92

Web: <http://www.linmot.com/>

USA

LinMot, Inc.
5750 Townline Road
Elkhorn, WI 53121

Sales and Administration: 877-546-3270
262-743-2555

Tech. Support: 877-804-0718
262-743-1284

Fax: 800-463-8708
262-723-6688

E-Mail: us-sales@linmot.com

Web: <http://www.linmot-usa.com/>

Please visit <http://www.linmot.com/> to find the distribution near you.

Smart solutions are...

