

EC Motors with E1100 Series Controllers

© 2006 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG. Reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement. Please refer to the latest edition of our "General business terms"


Document version 1.1 June 2006

1 Introduction


Since LinMot-Talk1100 software release 3.4 it is possible to run 3 phase rotary EC motors on E1100 series servo controllers.

2 Configuration

The rotary EC motors are configured by using the LinMot-Talk1100 configuration software. For a couple of motor types LinMot provides Actuator Definition Files (*.adf). With such an ADF-file the motor configuration can be done by using the *Motor Wizard* tool of the LinMot-Talk1100 software.



You will find the EC motor ADF-files in the subdirectory \Motors\Other Motors\EC Motors of your LinMot-Talk1100 installation.



After you have selected an EC motor ADF-file, the *Motor Wizard* will guide you step by step through the configuration.

3 Motors with ADF-File

3.1 *Berger Lahr RECM*

Supported Types:	RECM 372/4 DC048 xI RECM 374/4 DC048 xI RECM 375/4 DC060 xI RECM 377/4 DC060 xI
Feedback	Hall Switches & ABZ Encoder
Wiring:	<ul style="list-style-type: none">- Motor Phases U,V,W and PE Earth to X2 (X3 alternatively)- Hall Switches U, V, W to X10 (U->A, V->B, W->Z)- RS422 ABZ Encoder Signals to X12- Sensor supply (5V) from X12
Commutation	<ul style="list-style-type: none">- Based on Hall Switches until first Z pulse from Encoder- Based on Encoder signals afterwards (Sine Commutation)
Position Control	<ul style="list-style-type: none">- Based on feedback from ABZ encoder

3.2 *Faulhaber EC Motors*

Supported Types:	1628 T 024 B K1155 2036 U 024 B K1155 2036 U 036 B K1155 2444 S 024 B K1155 2444 S 048 B K1155 3056 K 024 B K1155 3056 K 036 B K1155 3564 K 024 B K1155 3564 K 036 B K1155 4490 H 024 B K1155 4490 H 048 B K1155
Feedback	Analog Hall Sensors & Optional Encoder
Wiring:	<ul style="list-style-type: none">- Motor Phases A,B,C to X3 (X2 alternatively) (A-> U, B->V, C->W)- Hall Sensors A,B,C to X3 (A->X4.4, B->X4.9, C->X4.5)- Optional Encoder to X12
Commutation:	<ul style="list-style-type: none">- Based on hall sensor signals
Position Control:	<ul style="list-style-type: none">- Based on hall sensor signals or optional encoder

3.3 Maxon EC Motors

Supported Types:	EC 22 167129 EC 32 118889 EC 32 118890 EC 40 167181 EC 45 136209 EC 45 flat 251601 EC 60 167131
Feedback	Hall Switches & ABZ Encoder
Wiring:	<ul style="list-style-type: none">- Motor Phases 1,2,3 to X2 (X3 alternatively) (1 -> U, 2->V, 3->W)- Hall Switches 1, 2, 3 to X3 (1 -> X4.4, 2->X4.9, 3->X4.5)- RS422 ABZ Encoder Signals to X12- Sensor supply (5V) from X12
Commutation:	<ul style="list-style-type: none">- Based on Hall Switches until first rising edge on Hall Switch 1- Based on Encoder signals afterwards (Sine Commutation)
Position Control:	<ul style="list-style-type: none">- Based on feedback from ABZ encoder

3.4 Metronix APM Servo Motors (e.g. from Elmo Motion Control)

Supported Types:	APM SA01ACN-9 APM SB03ADK-9
Feedback	Hall Switches & ABZ Encoder
Wiring:	<ul style="list-style-type: none">- Motor Phases U,V,W and Ground to X2 (X3 alternatively)- Hall Switches U, V, W to X10 (U->A, V->B, W->Z)- RS422 ABZ Encoder Signals to X12- Sensor supply (5V) from X12
Commutation	<ul style="list-style-type: none">- Based on Hall Switches until first Z pulse from Encoder- Based on Encoder signals afterwards (Sine Commutation)
Position Control	<ul style="list-style-type: none">- Based on feedback from ABZ encoder

3.5 Tetra Brushless Servo Motors

Supported Types:	T56SR1.35.E.L.08 T85SR2.2.E.L.12
Feedback	Hall Switches & ABZ Encoder
Wiring:	<ul style="list-style-type: none">- Motor Phases U,V,W and Earth to X2 (X3 alternatively)- Hall Switches U, V, W to X10 (U->A, V->B, W->Z)- RS422 ABZ Encoder Signals to X12- Sensor supply (5V) from X12
Commutation	<ul style="list-style-type: none">- Based on Hall Switches until first Z pulse from Encoder- Based on Encoder signals afterwards (Sine Commutation)
Position Control	<ul style="list-style-type: none">- Based on feedback from ABZ encoder