


# ***LinMot®***



## **MotionLink System**

Installation Guide

This document applies to the following controllers:

B8050-ML-PL

B8050-ML-EC

B8050-ML-IP

B8050-ML-PN

B8050-ML-SC

B1150-ML(-HC, -XC)

© 2010 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 1.0 / mk, September 2010

## Table of Content

|  |           |
|--|-----------|
| <b>1 Installation Guide B1150-ML-xx</b>          | <b>4</b>  |
| 1.1 Important notes for B1150 series controllers | 4         |
| 1.2 System Overview                              | 5         |
| 1.3 B1100 Interfaces                             | 6         |
| 1.4 Functionality                                | 7         |
| 1.5 Software                                     | 7         |
| 1.6 Power Supply and Grounding                   | 8         |
| 1.7 Description of the connectors / Interfaces   | 9         |
| 1.7.1 X1   | 9         |
| 1.7.2 X2   | 9         |
| 1.7.3 X3   | 10        |
| 1.7.4 X13  | 11        |
| 1.7.5 X14  | 12        |
| 1.7.6 X21-X22                                    | 13        |
| 1.7.7 X23  | 13        |
| 1.7.8 S6   | 13        |
| 1.7.9 LED  | 13        |
| 1.8 MotionLink Termination Settings              | 14        |
| 1.9 Physical Dimension                           | 14        |
| 1.10 Power Supply Requirement                    | 15        |
| 1.11 Ordering Information                        | 16        |
| 1.12 International Certifications                | 16        |
| 1.13 Declaration of Conformity CE-Marking        | 17        |
| <b>2 Installation Guide B8050-ML-xx</b>          | <b>18</b> |
| 2.1 Important notes for B8000 series controllers | 18        |
| 2.2 B8000 Interfaces                             | 19        |
| 2.3 Functionality                                | 20        |
| 2.4 MotionLink Multi-Axes Cabling                | 20        |
| 2.4.1 8 Axes System                              | 21        |
| 2.4.2 4 Axes System                              | 21        |
| 2.5 Power Supply and Grounding                   | 22        |
| 2.6 Description of the connectors / Interfaces   | 23        |
| 2.6.1 X17-X18                                    | 23        |
| 2.6.2 X23  | 23        |
| 2.6.3 X24  | 23        |
| 2.6.4 X25 - X28                                  | 24        |
| 2.6.5 S1 - S2                                    | 24        |
| 2.6.6 LED  | 24        |
| 2.6.7 RT BUS LED                                 | 24        |
| 2.7 Physical Dimension                           | 25        |
| 2.8 Power Supply Requirement                     | 26        |
| 2.9 Ordering Information                         | 26        |
| 2.10 International Certifications                | 26        |
| 2.11 Declaration of Conformity CE-Marking        | 27        |
| <b>3 Contact Addresses</b>                       | <b>28</b> |

## 1 Installation Guide B1150-ML-xx

### 1.1 Important notes for B1150 series controllers

#### CAUTION!



In order to assure a safe and error free operation, and to avoid severe damage to system components, all system components must be directly attached to a single ground bus that is earth or utility grounded.



Each system component should be tied directly to the ground bus (star pattern), rather than daisy chaining from component to component. (LinMot motors are properly grounded through their power cables when connected to LinMot controllers).



All connectors must not be connected or disconnected while DC voltage is applied. Do not disconnect system components until all LinMot controllers LEDs have turned off. (Capacitors in the power supply may not fully discharge for several minutes after input voltage has been disconnected). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or controllers.




Do not switch Power Supply DC Voltage. All power supply switching and E-Stop breaks should be done to the AC supply voltage of the power supply.




Do not connect or disconnect the motors from controllers while voltage is applied. Wait to connect or disconnect motors until all LinMot controllers LEDs have turned off. (Capacitors may not fully discharge for several minutes after power has been turned off). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or controllers.

## 1.2 System Overview



Typical servo system B1150-ML-xx: Servo controller, motor and power supply.

## 1.3 B1100 Interfaces



| B1150-ML-XX |  |   |
|-------------|--|---|
| Connector   |  |   |
| X1          | Motor Supply   | • |
| X2          | Motor Phases (Screw Terminals)   | • |
| X3          | Motor / Motor Signals  | • |
| X13         | External/Simulated Position Encoder<br>Diff Hall Switches  | • |
| X14         | 6 Digital Inputs<br>6 Digital Outputs<br>Analog In 0..10V<br>Analog In -10V.. +10V<br>Diff Step Dir zero<br>24V Logic Supply | • |
| X21         | MotionLink In  | • |
| X22         | MotionLink Out   | • |
| X23         | Com / Config RS232   | • |
| LED         | State Indicator  | • |
| S6          | MotionLink Termination   | • |


## 1.4 Functionality

|  | B1150-ML | B1150-ML-HC | B1150-ML-XC |
|--|----------|-------------|-------------|
| <b>Supply Voltage</b>                              |          |             |             |
| Motor Supply 72VDC (24...85VDC)                    | •        | •           | •           |
| Logic Supply 24VDC (22...26VDC)                    | •        | •           | •           |
| <b>Motor Phase Current</b>                         |          |             |             |
| 8A <sub>peak</sub> / 6A <sub>rms</sub>             | •        |             |             |
| 15A <sub>peak</sub> / 9A <sub>rms</sub>            |          | •           |             |
| 25A <sub>peak</sub> / 12A <sub>rms</sub>           |          |             | •           |
| <b>Controllable Motors</b>                         |          |             |             |
| LinMot P01-23x...                                  | •        | •           | •           |
| P01-37x...   | •        | •           | •           |
| P01-48x...   | •        | •           | •           |
| DC Motors  | •        | •           | •           |
| Brushless DC / EC Motors                           | •        | •           | •           |
| <b>Command Interface</b>                           |          |             |             |
| Easy Steps Max. 6 Commands                         | •        | •           | •           |
| +/-10V Current Command Interface                   | •        | •           | •           |
| Step Direction Indexer Interface                   | •        | •           | •           |
| Cmd Tab IO Interface (X14-IOs)<br>(with EasySteps) | •        | •           | •           |
| MotionLink   | •        | •           | •           |
| <b>External Position Sensor</b>                    |          |             |             |
| Incremental RS422 up to 2 MHz                      | •        | •           | •           |
| <b>Position Indexer Input</b>                      |          |             |             |
| Step Dir Zero/ ABZ RS422 up to 2 MHz               | •        | •           | •           |
| <b>Position Encoder Simulation</b>                 |          |             |             |
| AB RS422 up to 2.5 MHz                             | •        | •           | •           |
| <b>Configuration</b>                               |          |             |             |
| RS232 Configuration                                | •        | •           | •           |
| <b>MotionLink Bus-ID</b>                           |          |             |             |
| Automatically obtained via Cable Select            | •        | •           | •           |

## 1.5 Software

The configuration software LinMot-Talk is free of charge and can be downloaded from the LinMot homepage ([www.LinMot.com](http://www.LinMot.com)).

## 1.6 Power Supply and Grounding



In order to assure a safe and error free operation and to avoid severe damage to system components, **all system components\* must be well grounded to either a single earth or utility ground.** This includes both LinMot and all other control system components to the same ground bus.



Each system component\* should be tied directly to the ground bus (**star pattern**), rather than daisy chaining from component to component. (LinMot motors are properly grounded through their power cables when connected to LinMot controllers.)



**Power supply connectors must not be connected or disconnected while DC voltage is present.** Do not disconnect system components until all LinMot controllers LEDs have turned off. (Capacitors in the power supply may not fully discharge for several minutes after input voltage has been disconnected). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or controllers.





**Do not switch Power Supply DC Voltage.** All power supply switching and E-Stop breaks should be done to the AC supply voltage of the power supply. Failure to observe these precautions may result in severe damage to controller.

\* Inside of the B1150 controller the *PWR motor GND* and *PWR signal GND* is connected together and to the GND of the controller housing. It is recommended that the *PWR motor GND* is NOT grounded at another place than inside of the controller to avoid circular currents.




## 1.7 Description of the connectors / Interfaces



### 1.7.1 X1

| X1 Motor Supply  |   |
|--|---|
|  <p>PWR+<br/>PGND</p> |  <p>M5 PE Screw</p> <p>10AT/16AT</p> <p>PWR+ →</p> <p>PGND →</p> <p>X1</p> <p>24...85VDC</p> <p>GND</p> <p>GND internally connected to controller housing which is connected to PE</p>  |
| Screw Terminals  | <p>Motor Supply: 72VDC nominal, 24...85VDC<br/>Absolute max. Rating: 72VDC +20%.</p> <p>External Fuse: 10AT for LC (8Apeak), 16AT for HC and XC (15A/25Apeak) servos.</p> <p>If motor supply voltage exceeds 90VDC, the controller will go into error state.</p> <ul style="list-style-type: none"> <li>- Tightening Torque: min 0.4Nm</li> <li>- Screw Thread: M 2,5</li> <li>- Use 60/75°C copper conductors only</li> <li>- Conductor Cross-Section 2.5mm<sup>2</sup> (AWG14) max Length 4m</li> </ul> |


### 1.7.2 X2

| X2  |   | Motor Phases  |   |
|---|---|---|---|
| <div><div>1+ U</div><div>1- V</div><div>2+ W</div><div>2- X</div><div>SCRN</div></div> <div></div> | <div>PH1+ /U</div> <div>PH1- /V</div> <div>PH2+ /W</div> <div>PH2- /X</div> <div>SCRN</div> | <div>LinMot Motor:</div> <div>Motor Phase 1+ red</div> <div>Motor Phase 1- pink</div> <div>Motor Phase 2+ blue</div> <div>Motor Phase 2- grey</div> <div>Shield</div>   | <div>3-phase EC-Motor:</div> <div>Motor Phase U</div> <div>Motor Phase V</div> <div>Motor Phase W</div> |
| <div>Screw Terminals</div>  |   | <div>The motor phases are present at X2 and X3. It is recommended to use X2. It is only allowed to use X3 for connecting motor phases if RMS current is below 2A and peak current is below 4A.</div> <div>Never connect motor phases on X2 and X3!</div> <div>- Tightening Torque: min 0.4Nm</div> <div>- Screw Thread: M 2,5</div> <div>- Conductor Cross-Section: max. 2.5mm²</div> <div>- Use 60/75°C copper conductors only</div> |   |

## 1.7.3 X3

| X3  | Motor  |
|---|--|
|            | <div style="display: flex; justify-content: space-between;"> <div> <p><b>LinMot Motor:</b></p> <p>1 Motor Phase 1+</p> <p>2 Motor Phase 2+</p> <p>3 +5VDC</p> <p>4 Sensor Sine</p> <p>5 Temp. In</p> <p>6 Motor Phase 1-</p> <p>7 Motor Phase 2-</p> <p>8 AGND</p> <p>9 Sensor Cosine</p> <p>case Shield</p> </div> <div> <p><b>3-phase EC-Motor:</b></p> <p>+5VDC (Hall Supply)</p> <p>Hall 1</p> <p>Hall 3</p> <p>AGND (Hall Supply)</p> <p>Hall 2</p> </div> </div> |
| DSUB-9 (f)  | <p><u>Note:</u><br/>Use +5V (X3.3) and AGND (X3.8) only for motor internal hall sensor supply (max. 100mA).</p> <p><u>Caution:</u><br/>Do NOT connect AGND (X3.8) to ground or earth!<br/>It is only allowed to use X3 for connecting the motor phases if RMS current is below 2A and peak current below 4A.</p>   |
| <b>Motor Wiring for Phase Currents above 2A RMS or 4A peak (recommended general wiring)</b> |  |
|   |   |
|   | <p><b>Important:</b><br/>If motor phase current exceeds 2A<sub>RMS</sub> or 4A<sub>peak</sub>, motor phases must be wired to X2!</p>   |

### Motor wiring for Phase Currents below 2A RMS and 4A peak




**Important:**

**Motor phases may only be connected to X3 if RMS current is below 2A and peak current is below 4A!**

### 1.7.4 X13

### X13 External Position Sensor Differential Hall Switches



|      |    |        |               |
|------|----|--------|---------------|
| 1    | 9  | +5V DC |               |
| 2    | 10 | A-     | A+            |
| 3    | 11 | B-     | B+            |
| 4    | 12 | Z-     | Z+            |
| 5    | 13 | GND    | Encoder Alarm |
| 6    | 14 | U-     | U+            |
| 7    | 15 | V-     | V+            |
| 8    |    | W-     | W+            |
| case |    | Shield |               |

DSUB-15 (f)

## Position Encoder Inputs (RS422):

Max Input Frequency: 2MHz, 4 M counts/s with quadrature decoding, 240ns edge separation

### Encoder Simulation Outputs (RS422):

Max Output Frequency: 2.5MHz, 5 M counts/s with quadrature decoding, 200ns edge separation

### Differential Hall Switch Inputs (RS422):

Input Frequency: <1kHz



## Enc. Alarm In:

5V / 1mA


Sensor Supply:

5VDC max 100mA


## 1.7.5 X14

| X14   | 24VDC Supply and IOs   |
|---|--|
|  |  <p>*** internal pull down resistor 10k to GND</p> <p>** output with internal pull down resistor 1k6 to GND</p> <p>* outputs with internal pull down resistor 4k7 to GND</p> <p>+24V DC Output Supply</p> <p>Outputs (max. 100mA)</p> <p>+24V Inputs</p>  |
| DSUB-25 (f)   | <p><u>Logic Supply:</u><br/>Switch Mode Power Supply: 24VDC (22...26VDC)<br/>External Fuse: 2AT</p> <p><u>All Digital Inputs:</u><br/>Direct interfacing to digital 24VDC PLC outputs.<br/>Input Current: 1mA<br/>Logic Levels: Low Level: guaranteed: -5 to 5VDC, typically &lt; 8VDC<br/>High Level guaranteed: 20...30VDC, typically &gt; 16VDC<br/>Sample Rate: 400us</p> <p><u>All Digital Outputs:</u><br/>Short circuit and overload protected high side switches.<br/>Voltage: 24VDC<br/>Update Rate: 400us<br/>Max. Current: 100mA / 500mA for X14.17<br/>Peak Current: 370mA / 1100mA for X14.17</p> <p>Outputs may directly drive inductive loads. Do not connect any capacity because of the peak current!</p> <p><u>Analog Input on X14.20:</u><br/>Range: 0V...+10V 10Bit ADC<br/>Sample Rate: 400us</p> <p><u>Differential Analog Input on X14.8 X14.21 X14.9 Shield:</u><br/>Range: -10V...+10V 10Bit ADC<br/>Sample Rate: 400us</p> <p><u>Differential Step Dir Zero:</u><br/>Indexer Inputs: RS422, Max. Input Frequency: 2MHz, 4 M counts/s with quadrature decoding, 240ns edge separation</p> |


### 1.7.6 X21-X22

| X21 - X22   | MotionLink   |  |
|---|--|--|
|  | 1 ML1+<br>2 ML1-<br>3 ML2+<br>4 Cable Select<br>5 GND<br>6 ML2-<br>7 ML3+<br>8 ML3-<br>case Shield |  |
| RJ-45   | Use MotionLink cables (Art.-No. 0150-3308)   |  |


### 1.7.7 X23

| X23  | RS Config  |  |
|--|--|--|
|  | 1 (Do not connect)<br>2 RS232_Tx<br>3 RS232_Rx<br>4 (Do not connect)<br>5 GND<br>6 (Do not connect)<br>7 (Do not connect)<br>8 (Do not connect)<br>9 (Do not connect)<br>case Shield |  |
| DSUB-9 (m)   | RS232: Configuration on all controllers: use 1:1 connection cable to PC with only Pins 2,3 and 5 connected. Use LinMot RS Config Cable (Art.-No. 0150-3307)                          |  |

### 1.7.8 S6

| S6  | MotionLink Termination |  |
|---|------------------------|--|
|  | S6                     | Switch 4: Bootstrap<br>Switch 3: Termination A on/off<br>Switch 2: Termination B on/off<br>Switch 1: Not used<br><br>Factory settings: Switch 3 "on", all other switches "off" |


### 1.7.9 LED

| LED   | State Display |                              |
|---|---------------|------------------------------|
|  | Green<br>Red  | 24V Logic Supply OK<br>Error |

## 1.8 MotionLink Termination Settings

Termination A (S6.3) has to be set on every B1150 controller of a MotionLink connection.

## 1.9 Physical Dimension



**B1150** Single axis controller

|                              |         |   |
|------------------------------|---------|---|
| Width                        | mm (in) | 31 (1.3)  |
| Height                       | mm (in) | 166 (6.6)   |
| Height with fixings          | mm (in) | 206 (8.1)   |
| Depth                        | mm (in) | 106 (4.2)   |
| Weight                       | g (lb)  | 700 (1.6)   |
| Case                         | IP      | 20  |
| Storage Temperature          | °C      | -25...40  |
| Transport Temperature        | °C      | -25...70  |
| Operating Temperature        | °C      | 0...40 at rated data<br>40...50 with power derating                   |
| Relative humidity            |         | 95% (non-condensing)  |
| Max. Case Temperature        | °C      | 70  |
| Max. Power Dissipation       | W       | 30  |
| Distance between Controllers | mm (in) | 15 (0.8) left/right<br>50 (2) top<br>100 (4) bottom<br>90 (3.5) front |

## 1.10 Power Supply Requirement

### Motor Power Supply

The calculation of the needed power for the motor supply depends on the application and the used motor. The nominal supply voltage is 72 VDC. The possible range is from 24 to 85 VDC.



**ATTENTION:** The motor supply can rise up to 95 VDC when braking. This means that everything connected to that power supply needs a voltage rating of 100 VDC. (Additional capacitors, etc...)



To provide short circuit power limitation, it is required to use an external fuse (10AT for blank labeled (LC) and 16AT for HC and XC labeled controllers).

### Recommended Power supplies:

| Item           | Description                                       | Art. No.  |
|----------------|---|-----------|
| T01-72/420     | 72VDC, 15A peak, 420VA, 3x400VAC                  | 0150-1966 |
| T01-72/420-US  | 72VDC, 15A peak, 420VA, 3x230VAC                  | 0150-1967 |
| T01-72/900     | 72VDC, 30A peak, 900VA, 3x400VAC                  | 0150-1842 |
| T01-72/900-US  | 72VDC, 30A peak, 900VA, 3x230VAC                  | 0150-1843 |
| T01-72/1500    | 72VDC, 2x30A peak, 1500VA, 3x400VAC               | 0150-1844 |
| T01-72/1500-US | 72VDC, 2x30A peak, 1500VA, 3x230VAC               | 0150-1845 |
| S01-72/500     | 72VDC, 500W, 750W peak, 1x100..120VAC/200..240VAC | 0150-1874 |
| S01-72/1000    | 72VDC, 1000W, 2000W peak, 3x380..500VAC           | 0150-1872 |

### Signal Power Supply

The logic supply needs a regulated power supply with a nominal voltage of 24 VDC. The voltage must be between 22 and 26 VDC.

### Current Consumption

Min. 200mA (no load on the outputs)  
 Typ. 0.5A (all 6 outputs "on" with 50mA load and /Break with no load)  
 Max. 1.2A (all 6 outputs "on" with 100mA load and /Break with 0.5A load)




**To limit the power in case of malfunction, it is required to use an external fuse (2AT)!**

## 1.11 Ordering Information

| Servo Controller   | Description   | Art. No.  |
|--------------------|---|-----------|
| B1150-ML           | MotionLink Controller 72VDC / 8A                                  | 0150-1796 |
| B1150-ML-HC        | MotionLink Controller 72VDC / 15A                                 | 0150-1797 |
| B1150-ML-XC        | MotionLink Controller 72VDC / 25A                                 | 0150-1798 |
| Accessories        | Description   | Art. No.  |
| RS232 Config Cable | AC01-Df/Df-2-RS1<br>RS232 Config Cable DSUB9 f/f 2m (2-2/3-3/5-5) | 0150-3307 |
| Motion Link Cable  | AC01-RJ45/RJ45-0.2-ML1<br>MotionLink Cable 0.2m                   | 0150-3308 |

## 1.12 International Certifications

| Certifications  |   |
|---|---|
| Europe<br> | See chapter "1.13 Declaration of Conformity CE-Marking" |



## 1.13 Declaration of Conformity CE-Marking

Manufacturer: NTI AG *LinMot*®  
 Haerdlistrasse 15  
 8957 Spreitenbach  
 Switzerland  
 Tel.: +41 (0)56 419 91 91  
 Fax: +41 (0)56 419 91 92

Products: *LinMot*® Controllers

| Type        | Art.-No.  | Type | Art.-No. | Type | Art.-No. |
|-------------|-----------|------|----------|------|----------|
| B1150-ML    | 0150-1796 |      |          |      |          |
| B1150-ML-HC | 0150-1797 |      |          |      |          |
| B1150-ML-XC | 0150-1798 |      |          |      |          |

The product must be mounted and used in strict accordance with the installation instruction contained within the Installation Guide, a copy of which may be obtained from NTI Ltd.

I declare that as the authorized representative, the above information in relation to the supply/manufacture of this product is in conformity with the stated standards and other related documents in compliance with the protection requirements of the Electromagnetic Compatibility (EMC) Directive 2004/108/EC.

Standards Complied with:

| EN 61000-6-2 |              | Immunity for industrial environment |   |
|--------------|--------------|-------------------------------------|---|
|              | EN 61000-4-2 | Class B                             | Electrostatic discharge immunity (ESD)  |
|              | EN 61000-4-3 | Class A                             | Radiated electromagnetic field immunity |
|              | EN 61000-4-4 | Class B                             | Fast transients / burst immunity (EFT)  |
|              | EN 61000-4-5 | Class B                             | Slow transients immunity (Surges)       |
|              | EN 61000-4-6 | Class A                             | Conducted radio frequency immunity      |
| EN 61000-6-4 |              | Emission for industrial environment |   |
|              | EN 55022     | Class A                             | Radiated Emission                       |

Company  
 NTI Ltd.

Spreitenbach, September 07, 2010



-----  
 R. Rohner / CEO NTI AG

## 2 Installation Guide B8050-ML-xx

### 2.1 Important notes for B8000 series controllers

#### CAUTION!



In order to assure a safe and error free operation, and to avoid severe damage to system components, all system components must be directly attached to a single ground bus that is earth or utility grounded (see chapter Power Supply and Grounding).



Each system component should be tied directly to the ground bus (star pattern), rather than daisy chaining from component to component. (see chapter Power Supply and Grounding).




All connectors must not be connected or disconnected while DC voltage is applied. Do not disconnect system components until all LinMot controller LEDs have turned off. (Capacitors in the power supply may not fully discharge for several minutes after input voltage has been disconnected). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or controllers.



Do not switch Power Supply DC Voltage. All power supply switching and E-Stop breaks should be done to the AC supply voltage of the power supply.

## 2.2 B8000 Interfaces



|            |                  | B8050-ML-XX |
|------------|------------------|-------------|
| Connector  |                  |             |
| X17        | RT ETH In        | •           |
| X18        | RT ETH Out       | •           |
| X23        | RS Config        | •           |
| X24        | Supply           | •           |
| X25        | MotionLink 1     | •           |
| X26        | MotionLink 2     | •           |
| X27        | MotionLink 3     | •           |
| X28        | MotionLink 4     | •           |
| RT Bus LED | RT Bus Indicator | •           |
| State LED  | State Indicator  | •           |
| S1         | ID Switch High   | •           |
| S2         | ID Switch Low    | •           |

## 2.3 Functionality

|                                 | B8050-ML-PL | B8050-ML-PN | B8050-ML-SC | B8050-ML-IP | B8050-ML-EC |
|---------------------------------|-------------|-------------|-------------|-------------|-------------|
| <b>Supply Voltage</b>           |             |             |             |             |             |
| Logic Supply 24VDC (22...26VDC) | •           | •           | •           | •           | •           |
| <b>Command Interface</b>        |             |             |             |             |             |
| POWERLINK                       | •           |             |             |             |             |
| PROFINET                        |             | •           |             |             |             |
| SERCOS III                      |             |             | •           |             |             |
| ETHERNET IP                     |             |             |             | •           |             |
| ETHERCAT                        |             |             |             |             | •           |
| <b>Motion Interface</b>         |             |             |             |             |             |
| MotionLink                      | •           | •           | •           | •           | •           |
| <b>Configuration Interface</b>  |             |             |             |             |             |
| RS232                           | •           | •           | •           | •           | •           |

## 2.4 MotionLink Multi-Axes Cabling



All components of a MotionLink system must be referenced to the same ground! The same 24VDC supply must be used for all components!



Use only LinMot MotionLink cable (Art.-No. 0150-3308) to connect MotionLink devices! Longer cables must not be used!




For configuration via RS232 use 1:1 connection cable to PC with only Pins 2, 3 and 5 connected!  
Use LinMot RS Config Cable (Art.-No. 0150-3307).




Cabling has to be done exactly as depicted in this chapter!  
Do not connect more than two devices per MotionLink connector!


### 2.4.1 8 Axes System



### 2.4.2 4 Axes System



## 2.5 Power Supply and Grounding



In order to assure a safe and error free operation, and to avoid severe damage to system components, **all system components must be well grounded to either a single earth or utility ground.** This includes both LinMot and all other control system components to the same ground bus.



Each system component should be tied directly to the ground bus (**star pattern**), rather than daisy chaining from component to component.




**Power supply connectors must not be connected or disconnected while DC voltage is present.** Do not disconnect system components until all LinMot controller LED's have turned off. (Capacitors in the power supply may not fully discharge for several minutes after input voltage has been disconnected). Failure to observe these precautions may result in severe damage to electronic components in LinMot motors and/or controllers.




**Do not switch Power Supply DC Voltage.** All power supply switching and E-Stop breaks should be done to the AC supply voltage of the power supply. Failure to observe these precautions may result in severe damage to controller.

## 2.6 Description of the connectors / Interfaces


### 2.6.1 X17-X18

| X17 - X18   | RealTime Ethernet 10/100Mbit/s |  |
|---|--------------------------------|--|
|  | X17<br>RT ETH In               | Specification depends on RT-Bus type. Please refer to according documentation. |
|   | X18<br>RT ETH Out              |  |




### 2.6.2 X23

| X23   | RS Config   |                  |
|---|---|------------------|
|  | 1   | (Do not connect) |
|   | 2   | RS232_Tx         |
|   | 3   | RS232_Rx         |
|   | 4   | (Do not connect) |
|   | 5   | GND              |
|   | 6   | (Do not connect) |
|   | 7   | (Do not connect) |
|   | 8   | (Do not connect) |
|   | 9   | (Do not connect) |
|   | case  | Shield           |
| DSUB-9 (m)  | RS232: Configuration on all controllers: use 1:1 connection cable to PC with only Pins 2,3 and 5 connected. Use LinMot RS Config Cable (Art.-No. 0150-3307) |                  |



### 2.6.3 X24

| X24   | Supply   |                            |
|---|--|----------------------------|
|  | 2  | +24VDC Supply (22 – 26VDC) |
|   | 1  | GND Supply                 |
| Phoenix, SPT 1,5/2-H-3,5  | Supply 24V / typ. 150mA<br>- Stripping Length: 10mm<br>- Connection in acc. with standard: EN-VDE<br>- Use 60/75°C copper conductors only<br>- Conductor cross-section max. 1.5mm <sup>2</sup> |                            |


## 2.6.4 X25 - X28

| X25 - X28   |      |          |  | MotionLink 1 (X25) / MotionLink 2 (X26) / MotionLink 3 (X27) / MotionLink 4 (X28) |   |   |  |   |
|---|------|----------|--|---|---|---|--|---|
|  | 1    | MLConn 1 |  |   |  | <b>Use only LinMot MotionLink cable 0.2m for cabling! (0150-3308)</b><br><b>Longer cables must not be used!</b> |  |  |
|   | 2    | MLConn 2 |  |   |   |   |  |   |
|   | 3    | MLConn 3 |  |   |   |   |  |   |
|   | 4    | MLConn 4 |  |   |   | All devices, which are connected to X25 / X26 / X27 / X28 must be referenced to the same ground!                |  |   |
|   | 5    | MLConn 5 |  |   |   |   |  |   |
|   | 6    | MLConn 6 |  |   |   |   |  |   |
|   | 7    | MLConn 7 |  |   |   |   |  |   |
|   | 8    | MLConn 8 |  |   |   |   |  |   |
|   | case | Shield   |  |   |   |   |  |   |
| RJ-45   |      |          |  |   |   |   |  |   |


## 2.6.5 S1 - S2

| S1 - S2   |    | Address Selectors   |  |
|---|----|---|--|
| <br> | S1 | Bus ID High (0 ... F)   |  |
|   | S2 | Bus ID Low (0 ... F)  |  |
|   |    | The use of these switches depends on the type of fieldbus which is used. Please see the corresponding manual for further information. |  |

## 2.6.6 LED


| LED   | State Display |                              |
|---|---------------|------------------------------|
|  | Green<br>Red  | 24V Logic Supply OK<br>Error |

## 2.6.7 RT BUS LED

| RT Bus LED  | RT Bus State Display |             |
|---|----------------------|-------------|
|    | Green<br>Red         | OK<br>Error |
| The use of these LEDs depends on the type of fieldbus which is used. Please see the corresponding manual for further information. |                      |             |



## 2.7 Physical Dimension



**B8000 Series MotionLink controller**

|                              |         |   |
|------------------------------|---------|---|
| Width                        | mm (in) | 31 (1.3)  |
| Height                       | mm (in) | 166 (6.6)   |
| Height with fixings          | mm (in) | 206 (8.1)   |
| Depth                        | mm (in) | 106 (4.2)   |
| Weight                       | g (lb)  | 650 (1.5)   |
| Case                         | IP      | 20  |
| Storage Temperature          | °C      | -25...40  |
| Transport Temperature        | °C      | -25...70  |
| Operating Temperature        | °C      | 0...40 at rated data  |
| Relative humidity            |         | 95% (non-condensing)  |
| Max. Case Temperature        | °C      | 70  |
| Max. Power Dissipation       | W       | 6   |
| Distance between Controllers | mm (in) | 15 (0.8) left/right<br>50 (2) top<br>100 (4) bottom<br>90 (3.5) front |

## 2.8 Power Supply Requirement

### Signal Power Supply

The logic supply needs a regulated power supply with a nominal voltage of 24 VDC. The voltage must be between 22 and 26 VDC.

### Current Consumption

Min. 100mA


**Typ. 150mA**

Max. 250mA

## 2.9 Ordering Information

| Servo Controller   | Description                                     | Art. No.  |
|--------------------|---|-----------|
| B8050-ML-PL        | POWERLINK MotionLink Master                     | 0150-1877 |
| B8050-ML-EC        | ETHERCAT MotionLink Master                      | 0150-1878 |
| B8050-ML-IP        | ETHERNET IP MotionLink Master                   | 0150-1879 |
| B8050-ML-PN        | PROFINET MotionLink Master                      | 0150-1880 |
| B8050-ML-SC        | SERCOS III MotionLink Master                    | 0150-1881 |
| Accessories        | Description                                     | Art. No.  |
| RS232 Config Cable | AC01-Df/Df-2-RS1                                | 0150-3307 |
|                    | RS232 Config Cable DSUB9 f/f 2m (2-2/3-3/5-5)   |           |
| Motion Link Cable  | AC01-RJ45/RJ45-0.2-ML1<br>MotionLink Cable 0.2m | 0150-3308 |

## 2.10 International Certifications

| Certifications  |   |
|---|---|
| Europe<br> | See chapter "2.11 Declaration of Conformity CE-Marking" |

## 2.11 Declaration of Conformity CE-Marking

Manufacturer: NTI AG *LinMot*®  
 Haerdlistrasse 15  
 8957 Spreitenbach  
 Switzerland  
 Tel.: +41 (0)56 419 91 91  
 Fax: +41 (0)56 419 91 92

Products: *LinMot*® Controllers

| Type        | Art.-No.  | Type        | Art.-No.  | Type | Art.-No. |
|-------------|-----------|-------------|-----------|------|----------|
| B8050-ML-PL | 0150-1877 | B8050-ML-PN | 0150-1880 |      |          |
| B8050-ML-EC | 0150-1878 | B8050-ML-SC | 0150-1881 |      |          |
| B8050-ML-IP | 0150-1879 |             |           |      |          |

The product must be mounted and used in strict accordance with the installation instruction contained within the Installation Guide, a copy of which may be obtained from NTI Ltd.

I declare that as the authorized representative, the above information in relation to the supply/manufacture of this product is in conformity with the stated standards and other related documents in compliance with the protection requirements of the Electromagnetic Compatibility (EMC) Directive 2004/108/EC.

Standards Complied with:

| EN 61000-6-2 |              | Immunity for industrial environment |   |
|--------------|--------------|-------------------------------------|---|
|              | EN 61000-4-2 | Class B                             | Electrostatic discharge immunity (ESD)  |
|              | EN 61000-4-3 | Class A                             | Radiated electromagnetic field immunity |
|              | EN 61000-4-4 | Class B                             | Fast transients / burst immunity (EFT)  |
|              | EN 61000-4-5 | Class B                             | Slow transients immunity (Surges)       |
|              | EN 61000-4-6 | Class A                             | Conducted radio frequency immunity      |
| EN 61000-6-4 |              | Emission for industrial environment |   |
|              | EN 55022     | Class A                             | Radiated Emission                       |

Company  
 NTI Ltd.

Spreitenbach, September 07, 2010



-----  
 R. Rohner / CEO NTI AG

### 3 Contact Addresses

**SWITZERLAND****NTI AG**

Haerdlistr. 15  
CH-8957 Spreitenbach

**Sales and Administration:**

+41-(0)56-419 91 91  
office@linmot.com

**Tech. Support:**

+41-(0)56-544 71 00  
support@linmot.com

**Tech. Support (Skype) :**

skype:support.linmot

**Fax:**

+41-(0)56-419 91 92

**Web:**

<http://www.linmot.com/>

**USA****LinMot, Inc.**

5750 Townline Road  
Elkhorn, WI 53121

**Sales and Administration:**

877-546-3270  
262-743-2555

**Tech. Support:**

877-804-0718  
262-743-1284

**Fax:**

800-463-8708  
262-723-6688

**E-Mail:**

us-sales@linmot.com

**Web:**

<http://www.linmot-usa.com/>

Please visit <http://www.linmot.com/> to find the distributor closest to you.

Smart solutions are...

