



## ***Sinoide Application SW***

**Documentation of the Sinoide Application SW**

**- E1100 / B1100 Servo Controller Series**



---

## **Sinoide Application SW**

**User Manual V3.14**

---

© 2011 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying,

recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG. reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document Version 3.14 / Whp, May 2011

**TABLE OF CONTENT**

<b>SYSTEM OVERVIEW .....</b>	<b>4</b>
1.1 REFERENCES .....	4
1.2 DEFINITIONS, ITEMS, SHORTCUTS .....	4
1.3 DATA TYPES .....	4
<b>2 INSTALLATION ON SERVO CONTROLLER .....</b>	<b>5</b>
<b>3 SINOIDE FUNCTIONALITY .....</b>	<b>6</b>
3.1 OVERVIEW MOTION COMMANDS .....	6
3.2 DETAILED MOTION COMMAND DESCRIPTION .....	7
3.2.1 <i>Sin VA Go To Pos (3E0xh)</i> .....	7
3.2.2 <i>Sin VA Increment Demand Pos (3E1xh)</i> .....	7
3.2.3 <i>Sin VA Go To Pos From Actual Pos (3E4xh)</i> .....	7
3.2.4 <i>Sin VA Increment Actual Pos (3E6xh)</i> .....	7
3.2.5 <i>Sin VA Go To Pos On Rising Trigger Event (3EAxh)</i> .....	8
3.2.6 <i>Sin VA Increment Demand Pos On Rising Trigger Event (3EBxh)</i> .....	8
3.2.7 <i>Sin VA Go To Pos On Falling Trigger Event (3ECxh)</i> .....	8
3.2.8 <i>Sin VA Increment Demand Pos On Falling Trigger Event (3EDxh)</i> .....	9
3.2.9 <i>Bestehorn VAJ Go To Pos (3F0xh)</i> .....	9
3.2.10 <i>Bestehorn VAJ Increment Demand Pos (3F1xh)</i> .....	9
3.2.11 <i>Bestehorn VAJ 16 Bit Go To Pos (3F2xh)</i> .....	10
3.2.12 <i>Bestehorn VAJ Go To Pos From Actual Pos (3F4xh)</i> .....	10
3.2.13 <i>Bestehorn VAJ Increment Actual Pos (3F6xh)</i> .....	10
3.2.14 <i>Bestehorn VAJ Go To Pos On Rising Trigger Event (3FAxh)</i> .....	11
3.2.15 <i>Bestehorn VAJ Increment Demand Pos On Rising Trigger Event (3FBxh)</i> ....	11
3.2.16 <i>Bestehorn VAJ Go To Pos On Falling Trigger Event (3FCxh)</i> .....	11
3.2.17 <i>Bestehorn VAJ Increment Demand Pos On Falling Trigger Event (3FDxh)</i> ..	12
<b>4 SETPOINT GENERATION .....</b>	<b>13</b>
4.1 SINE VA MOTION .....	13
4.1.1.1 Parameters and Output .....	13
4.2 BESTEHORN VAJ MOTION .....	14
4.2.1.1 Parameters and Output .....	14
<b>5 CONTACT ADDRESSES .....</b>	<b>15</b>

## System Overview

This user Manual describes the Sinoide Application SW functionality of the LinMot E1100 / B1100 servo controllers.

### 1.1 References

Ref	Title	Source
1	Installation_Guide_E1100.pdf	<a href="http://www.linmot.com">www.linmot.com</a>
2	Installation_Guide_B1100.pdf	<a href="http://www.linmot.com">www.linmot.com</a>
3	Usermanual_LinMot-Talk_4.pdf	<a href="http://www.linmot.com">www.linmot.com</a>

The documentation is distributed with the LinMot-Talk configuration software or can be downloaded from the Internet from the download section of our homepage.


### 1.2 Definitions, Items, Shortcuts


Shortcut	Meaning
LM	LinMot linear motor
OS	Operating system (Software)
MC (SW)	Motion Control (Software)
Intf	Interface (Software)
Appl	Application (Software)
VAI	VA-Interpolator (Max velocity limited acceleration position interpolator)
Pos	Position
Vel	Velocity
Acc	Acceleration
Dec	Deceleration
UPID	Unique Parameter ID (16 bit)

### 1.3 Data types

Type	Range/Format	Num of bytes
Bool	Boolean, False/True	1/8
Byte	0..255	1
Char	ASCII	1
String	Array of char last char = 00h	X
SInt16	-32768..32767	2
UInt16	0..65535	2
SInt32	-2147483648..2147483647	4
UInt32	0..4294967295	4

## 2 Installation on Servo Controller

For installing the Sinoide firmware on the servo controller, start the LinMot-Talk software and press the install firmware button . Choose the file “Firmware\_Buildxxxxxxx.sct” and press “Open”. The wizard will guide you through the installation. When asking for the application software choose “Sinoide”



Press ok and follow the rest of the wizard.

### 3 Sinoide Functionality

The Sinoide Application SW is a MC Motion Command Interface extension, with the Sinoide functionality. Additionally the Autostart application is included.

#### 3.1 Overview Motion Commands

Master ID	Sub ID	E 1 1 0 0	B 1 1 0 0	Description
3Eh	0h	X	X	Sin VA Go To Pos
	1h	X	X	Sin VA Increment Demand Pos
	4h	X	X	Sin VA Go To Pos From Actual Pos
	6h	X	X	Sin VA Increment Actual Pos
	Ah	X	X	Sin VA Go To Pos On Rising Trigger Event
	Bh	X	X	Sin VA Increment Demand Pos On Rising Trigger Event
	Ch	X	X	Sin VA Go To Pos On Falling Trigger Event
	Dh	X	X	Sin VA Increment Demand Pos On Falling Trigger Event
3Fh	0h	X	X	Bestehorn VAJ Go To Pos
	1h	X	X	Bestehorn VAJ Increment Demand Pos
	2h	X	X	Bestehorn VAJ 16 Bit Go To Pos
	4h	X	X	Bestehorn VAJ Go To Pos From Actual Pos
	6h	X	X	Bestehorn VAJ Increment Actual Pos
	Ah	X	X	Bestehorn VAJ Go To Pos On Rising Trigger Event
	Bh	X	X	Bestehorn VAJ Increment Demand Pos On Rising Trigger Event
	Ch	X	X	Bestehorn VAJ Go To Pos On Falling Trigger Event
	Dh	X	X	Bestehorn VAJ Increment Demand Pos On Falling Trigger Event

## 3.2 Detailed Motion Command Description

### 3.2.1 Sin VA Go To Pos (3E0xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3E0xh: Sin VA Go To Pos	UInt16	-
1. Par	2	Target Position	UInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

Half period sine motion profile, regarding the limitations of maximal acceleration and maximal velocity.

### 3.2.2 Sin VA Increment Demand Pos (3E1xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3E1xh: Sin VA Increment Demand Pos	UInt16	-
1. Par	2	Position Increment	UInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

Half period sine motion profile, regarding the limitations of maximal acceleration and maximal velocity. The new Target Position value will be determined by the firmware. It is calculated by adding the Position Increment argument to the Demand Position value (relative move). The command execution starts immediately when the command has been sent.

### 3.2.3 Sin VA Go To Pos From Actual Pos (3E4xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3E4xh: Sin VA Go To Pos From Actual Pos	UInt16	-
1. Par	2	Target Position	UInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

Half period sine motion profile, regarding the limitations of maximal acceleration and maximal velocity. The command execution starts immediately when the command has been sent. This command should be used if the Actual Position does not match with the current Demand Position value, but it can be assumed that the motor stands still (Actual Velocity assumed to be zero, e.g. because the motor stands on a hard stop). This can happen after a Press command, where the actual motor position is defined through external conditions and the motor could not and had not to follow the demand position. By starting this command, the former accepted difference between Actual Position and Demand Position can be eliminated.

### 3.2.4 Sin VA Increment Actual Pos (3E6xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3E6xh: Sin VA Increment Actual Pos	UInt16	-
1. Par	2	Position Increment	UInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

Half period sine motion profile, regarding the limitations of maximal acceleration and maximal velocity. The new Target Position value will be determined by the firmware. It is calculated by adding the Position Increment argument to the Actual Position value (relative move). The command execution starts immediately when the command has been sent.

### 3.2.5 Sin VA Go To Pos On Rising Trigger Event (3EAxh)

Name	Byte Offset	Description	Type	Unit
Header	0	0EAxh: Sin VA Go To Pos On Rising Trigger Event	UInt16	-
1. Par	2	Target Position	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

This command defines a new sine motion command (see description of command 'Sin VA Go To Pos (3E0xh)'). The command will be started on each rising edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Sin VA motion on the rising trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

### 3.2.6 Sin VA Increment Demand Pos On Rising Trigger Event (3EBxh)

Name	Byte Offset	Description	Type	Unit
Header	0	3EBxh: Sin VA Increment Demand Pos On Rising Trigger Event	UInt16	-
1. Par	2	Position Increment	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

This command defines a new Sin VA motion command (relative move, see description of command 'Sin VA Increment Demand Pos (3E1xh)'). The command will be started on each rising edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Sin VA motion on the rising trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

### 3.2.7 Sin VA Go To Pos On Falling Trigger Event (3ECxh)

Name	Byte Offset	Description	Type	Unit
Header	0	0ECxh: Sin VA Go To Pos On Falling Trigger Event	UInt16	-
1. Par	2	Target Position	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

This command defines a new Sin VA motion command (see description of command 'Sin VA Go To Pos (3E0xh)'). The command will be started on each falling edge on the Trigger



signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Sin VA motion on the falling trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

### 3.2.8 Sin VA Increment Demand Pos On Falling Trigger Event (3EDxh)

Name	Byte Offset	Description	Type	Unit
Header	0	3EDxh: Sin VA Increment Demand Pos On Falling Trigger Event	UInt16	-
1. Par	2	Position Increment	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>

This command defines a new Sin VA motion command (relative move, see description of command 'Sin VA Increment Demand Pos (0E1xh)'). The command will be started on each falling edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Sin VA motion on the falling trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

### 3.2.9 Bestehorn VAJ Go To Pos (3F0xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3F0xh: Bestehorn VAJ Go To Pos	UInt16	-
1. Par	2	Target Position	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

Bestehorn Motion Profile, regarding the limitations maximal jerk, acceleration and maximal speed.

### 3.2.10 Bestehorn VAJ Increment Demand Pos (3F1xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3F1xh: Bestehorn VAJ Increment Demand Pos	UInt16	-
1. Par	2	Position Increment	SLnt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

Bestehorn Motion Profile, regarding the limitations maximal jerk, acceleration and maximal speed. The new Target Position value will be determined by the firmware. It is calculated by adding the Position Increment argument to the Demand Position value (relative move). The command execution starts immediately when the command has been sent.

### 3.2.11 Bestehorn VAJ 16 Bit Go To Pos (3F2xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3F2xh: Bestehorn VAJ 16 Bit Go To Pos	UInt16	-
1. Par	2	Target Position	SInt16	Scaled
2. Par	4	Maximal Velocity	UInt16	Scaled
3. Par	6	Acceleration	UInt16	Scaled
4. Par	8	Jerk	UInt16	Scaled

Bestehorn Motion Profile, regarding the limitations maximal jerk, acceleration and maximal speed. With 16 bit motion parameters: UPID 1455h for Position, UPID 1456 for Maximal Velocity, UPID 1457h for Acceleration and UPID 1458h for Jerk Scaling.

### 3.2.12 Bestehorn VAJ Go To Pos From Actual Pos (3F4xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3F4xh: Bestehorn VAJ Go To Pos From Actual Pos	UInt16	-
1. Par	2	Target Position	SInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

Bestehorn Motion Profile, regarding the limitations maximal jerk, acceleration and maximal speed. The command execution starts immediately when the command has been sent. This command should be used if the Actual Position does not match with the current Demand Position value, but it can be assumed that the motor stands still (Actual Velocity assumed to be zero, e.g. because the motor stands on a hard stop). This can happen after a Press command where the actual motor position is defined through external conditions and the motor could not and had not to follow the demand position. By starting this command, the former accepted difference between Actual Position and Demand Position can be eliminated.

### 3.2.13 Bestehorn VAJ Increment Actual Pos (3F6xh)

Name	Byte Offset	Description	Type	Unit
Header	0	3F6xh: Bestehorn VAJ Increment Actual Pos	UInt16	-
1. Par	2	Position Increment	SInt32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

Bestehorn Motion Profile, regarding the limitations maximal jerk, acceleration and maximal speed. The new Target Position value will be determined by the firmware. It is calculated by adding the Position Increment argument to the Actual Position value (relative move). The command execution starts immediately when the command has been sent.

**3.2.14 Bestehorn VAJ Go To Pos On Rising Trigger Event (3FAxh)**

Name	Byte Offset	Description	Type	Unit
Header	0	3FAxh: Bestehorn VAJ Go To Pos On Rising Trigger Event	UInt16	-
1. Par	2	Target Position	Slnt32	0.1 um
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

This command defines a new Bestehorn motion command (see description of command Bestehorn VAJ Go To Pos (3F0xh)'). The command will be started on each rising edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Bestehorn motion on the rising trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

**3.2.15 Bestehorn VAJ Increment Demand Pos On Rising Trigger Event (3FBxh)**

Name	Byte Offset	Description	Type	Unit
Header	0	3FBxh: Bestehorn VAJ Increment Demand Pos On Rising Trigger Event	UInt16	-
1. Par	2	Position Increment	Slnt32	0.1 um
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

This command defines a new Bestehorn motion command (relative move\c see description of command Bestehorn VAJ Increment Demand Pos (3F1xh)'). The command will be started on each rising edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Bestehorn motion on the rising trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

**3.2.16 Bestehorn VAJ Go To Pos On Falling Trigger Event (3FCxh)**

Name	Byte Offset	Description	Type	Unit
Header	0	3FCxh: Bestehorn VAJ Go To Pos On Falling Trigger Event	UInt16	-
1. Par	2	Target Position	Slnt32	0.1 um
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

This command defines a new Bestehorn motion command (see description of command Bestehorn VAJ Go To Pos (3F0xh)'). The command will be started on each falling edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Bestehorn motion on the falling trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

### 3.2.17 Bestehorn VAJ Increment Demand Pos On Falling Trigger Event (3FDxh)


Name	Byte Offset	Description	Type	Unit
Header	0	3FDxh: Bestehorn VAJ Increment Demand Pos On Falling Trigger Event	UInt16	-
1. Par	2	Position Increment	Int32	0.1 $\mu\text{m}$
2. Par	6	Maximal Velocity	UInt32	1E-6 m/s
3. Par	10	Acceleration	UInt32	1E-5 m/s <sup>2</sup>
4. Par	14	Jerk	UInt32	1E-4 m/s <sup>3</sup>

This command defines a new Bestehorn motion command (relative move\c see description of command Bestehorn VAJ Increment Demand Pos (3F1xh)'). The command will be started on each falling edge on the Trigger signal. This command is used to synchronize the execution of the motion command to a hardware signal. The command activates the Event Handler (see Status Word bit 8). The Event Handler starts the new Bestehorn motion on the falling trigger event. The Event Handler can be deactivated by using the command 'Clear Event Evaluation (008xh)'. The trigger input must be configured with parameter <UPID>\$1039.

## 4 Setpoint Generation

### 4.1 Sine VA Motion

The Sine generates a position curve from one position to another due to the parameter values of target position, maximal speed and acceleration. A new target position can only be started when the previous motion was finished.



#### 4.1.1.1 Parameters and Output

The Sine Motion is defined by the following parameters:


- Target Position [SInt32; 0.1µm/s]
- Maximal Speed [UInt32; 1E-6 m/s]
- Acceleration [UInt32; 1E-5 m/s<sup>2</sup>]

The Sine Motion generates as outputs:

- Position [SInt32; 0.1µm]
- Velocity [SInt32; 1E-6 m/s]
- Acceleration [SInt32; 1E-5 m/s<sup>2</sup>]

## 4.2 Besthorn VAJ Motion

The Besthorn generates a position curve from one position to another due to the parameter values of target position, maximal speed acceleration and jerk. A new target position can only be started when the previous motion was finished.



### 4.2.1.1 Parameters and Output

The Besthorn Motion is defined by the following parameters:

- Target Position [SInt32; 0.1um/s]
- Maximal Speed [UInt32; 1E-6 m/s]
- Acceleration [UInt32; 1E-5 m/s<sup>2</sup>]
- Jerk [UInt32; 1E-4 m/s<sup>3</sup>]

The Besthorn Motion generates as outputs:

- Position [SInt32; 0.1um]
- Velocity [SInt32; 1E-6 m/s]
- Acceleration [SInt32; 1E-5 m/s<sup>2</sup>]

## 5 Contact Addresses

---

### SWITZERLAND

**NTI AG**  
Haerdlistr. 15  
CH-8957 Spreitenbach

**Sales and Administration:** +41-(0)56-419 91 91  
[office@linmot.com](mailto:office@linmot.com)

**Tech. Support:** +41-(0)56-544 71 00  
[support@linmot.com](mailto:support@linmot.com)

**Tech. Support (Skype) :** [skype:support.linmot](https://www.skype.com/contact/linmot)

**Fax:** +41-(0)56-419 91 92

**Web:** <http://www.linmot.com/>

---

### USA

**LinMot, Inc.**  
5750 Townline Road  
Elkhorn, WI 53121

**Sales and Administration:** 877-546-3270  
262-743-2555

**Tech. Support:** 877-804-0718  
262-743-1284

**Fax:** 800-463-8708  
262-723-6688

**E-Mail:** [us-sales@linmot.com](mailto:us-sales@linmot.com)

**Web:** <http://www.linmot-usa.com/>

---

Please visit <http://www.linmot.com/> to find the distribution near you.

Smart solutions are...

