




Documentation of the CANopen Interface of the following Controllers:

- E1100-CO (-HC,-XC)
- E1100-GP (-HC, -XC) (with CANopen Firmware loaded)
- B1100-GP (-HC, -XC) (with CANopen Firmware loaded)



CANopen Interface 3.9

User Manual

© 2008 NTI AG

This work is protected by copyright.

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, microfilm, storing in an information retrieval system, not even for didactical use, or translating, in whole or in part, without the prior written consent of NTI AG.

LinMot® is a registered trademark of NTI AG.

Note

The information in this documentation reflects the stage of development at the time of press and is therefore without obligation. NTI AG. Reserves itself the right to make changes at any time and without notice to reflect further technical advance or product improvement.

Document version 3.9 / FM / mk, August 2008

Table of Content

1 SYSTEM OVERVIEW.....	4
2 CONNECTING THE CAN BUS.....	4
2.1 PIN ASSIGNMENT OF THE COM CONNECTOR (X5).....	4
2.2 PIN ASSIGNMENT OF THE CMD CONNECTOR (X7, X8).....	4
2.3 CAN TERMINATION.....	5
2.3.1 E1100.....	5
2.3.2 B1100.....	5
3 CANOPEN PARAMETERS.....	6
4 MAPPING OF THE PDO'S.....	16
4.1 MAPPING TABLE.....	16
4.1.1 Receive PDO's.....	16
4.1.2 Transmit PDO's.....	16
4.1.3 Default Identifier.....	16
5 MOTOR COMMANDS.....	17
6 STATE MACHINE.....	17
7 INTERFACE ERROR CODES.....	17
8 WARNWORD.....	17
9 OBJECT DICTIONARY.....	18
9.1 E1100.....	18
9.2 B1100.....	21
10 EXAMPLES FOR CONTROLLERS OF THE E1100 SERIES.....	22
10.1 WRITE CURVE INTO THE CONTROLLER VIA CANOPEN.....	22
10.2 READ CURVE FROM CONTROLLER VIA CANOPEN.....	25
10.3 GET UPID LIST FROM CONTROLLER VIA CANOPEN.....	26
10.4 READ THE ERROR LOG FROM THE CONTROLLER.....	28
11 EXAMPLES FOR CONTROLLERS OF THE B1100 SERIES.....	30
11.1 READ THE VALUE OF A UPID FROM A B1100 CONTROLLER.....	30
11.2 WRITE THE VALUE OF A UPID TO A B1100 CONTROLLER.....	32
12 RESET PARAMETERS TO DEFAULT VALUES ON E1100.....	33
13 EXAMPLE FOR SETTING UP A MOTION COMMAND.....	34
14 QUICK START GUIDE FOR ADVANCED USERS.....	36
14.1 HARDWARE-SETUP.....	36
14.2 CONFIGURATION OF THE CONTROLLER.....	36
14.3 STARTING THE DEVICE.....	36
15 CONTACT ADDRESSES.....	37

1 System overview

The LinMot CANopen controllers support the communication profile CiA DS301. Further information on CANopen can be found under: <http://www.can-cia.de/>

The following resources are available:

- 3 T_PDO
- 3 R_PDO
- 1 T_SDO
- 1 R_SDO

The supported protocols include:


- NMT Error Control (Nodeguarding Protocol or HeartBeat Protocol)
- PDO (Transmission type 254, 250 and 1)
- SDO Upload and Download
- NMT (Start, Stop, Enter PreOp, Reset Node, Reset Communication)
- Boot-Up Message

The baud rate can be selected by parameter or directly by BTR (bit timing register).

2 Connecting the CAN bus

2.1 Pin assignment of the COM Connector (X5)


D-SUB 9 male:



Pin 1	RS-485 Y	Pin 6	RS-485 B
Pin 2	RS-232 TX	Pin 7	RS-485 Z
Pin 3	RS-232 RX	Pin 8	CAN L
Pin 4	RS-485 A	Pin 9	CAN H
Pin 5	GND		

2.2 Pin assignment of the CMD Connector (X7, X8)


The CMD connector exists only on the E1100-RS(-HC/-XC), E1100-DP(-HC/-XC) and B1100-GP(-HC/-XC) controllers, 2xRJ45 with 1:1 connected signals. Standard twisted pairs: 1/2, 3/6, 4/5, 7/8. Use Ethernet cables according the EIA / TIA 568A standard.



Pin 1	RS485 A
Pin 2	RS485 B
Pin 3	RS485 Y
Pin 4/5	Ground
Pin 6	RS485 Z
Pin 7	CAN H
Pin 8	CAN L

2.3 CAN Termination

The CANbus must be terminated by two 120 Ohm resistors at both ends of the bus line, according the following figure:



For easy installation, the LinMot CANopen controller has built in termination resistors, which can be activated, if the LinMot controller is at the end of the bus line, and if there is no termination in the connector.

2.3.1 E1100

S3
ON – OFF
Interface
CAN Term
RS485 Term
RS485/232



S3

The built in termination resistor for the CAN bus can be activated by setting the DIP switch “CAN Term” to “ON”.



ATTENTION: For normal operation S3.4 (Interface) has to be set to ON!

2.3.2 B1100

S4
ON – OFF
Bootstrap
CAN Term
RS485 Term
RS485/232



S4

The built in termination resistor for the CAN bus can be activated by setting the DIP switch “CAN Term” to “ON”.



ATTENTION: For normal operation S4.4 (Bootstrap) has to be set to OFF!

3 CANopen Parameters

The CANopen servo controllers have an additional parameter tree branch (Parameters → CANopen Interface), which can be configured with the distributed LinMot-Talk software. With these parameters, the CANopen behaviour can be defined. The LinMot-Talk software can be downloaded from <http://www.linmot.com> under the section download, software & manuals.

Dis-/Enable With the Dis-/Enable parameter the LinMot servo controller can be run without the CANopen going online. So in a first step the system can be configured and run without any bus connection.

CANopen Interface\ Dis-/Enable	
Disable	Servo controller runs without CANopen.
Enable	Servo controller runs only with a CANopen connection.



IMPORTANT: To activate the CANopen interface on E1100 controllers, the DIP switch “Interface” at the bottom of the drive has to be set to “ON”. This is not necessary for controllers of the B1100 series.

Baud Rate In this section the parameters for the baud rate selection are located.

Baud Rate Source Select

Defines the source of the baud rate definition.

E1100: CANopen Interface\ Baud Rate \Baud Rate Source Select		
B1100: OS\Communication\ CAN Configuration\ Baud Rate\ Baud Rate Source Select		
By Hex Switch S1 ¹	E1100 only: CAN bus baud rate dependent on S1 0 = By BTR 1 = 125 kBit/s 2 = 250 kBit/s 3 = 500 kBit/s 4 = 1 Mbit/s	
By Parameter	The CAN bus baud rate is selected by the “Baudrate Parameter”: - 125 kBit/s [1] - 250 kBit/s [2] - 500 kBit/s [3] - 1 Mbit/s [4]	
By BTR	CAN bus baud rate is defined according to the Bit Timing Register	
By DigIn 5 & 6 ²	The baud rate is defined through the state of DigIn5 and DigIn6 at startup. DigIn6 is the most, DigIn5 the least significant bit.	
	DigIn6	DigIn5 BaudRate
	0	0 125kBaud
	0	1 250kBaud
	1	0 500kBaud
	1	1 1MBaud

Baud Rate BTR Value

For special applications where no standard setting for the baud rate works this parameter defines the bit timing for the CAN bus. The setting of the baud rate by Bit Timing Register is only necessary on special bus configurations: For example, if there are devices on the bus that have slow optocouplers.

Baud Rate Parameter Definition

The baud rate parameter defines the CAN bus baud rate for the CANOpen connection.

CANOpen Interface\ Baud Rate\ Baud Rate Parameter Definition	
125 kBit/s	CAN bus baud rate = 125 kBit/s
250 kBit/s	CAN bus baud rate = 250 kBit/s
500 kBit/s	CAN bus baud rate = 500 kBit/s
1 Mbit/s	CAN bus baud rate = 1 Mbit/s

¹ Parameter **not** available on controllers of the B1100 series.

² Parameter **only** available on controllers of the B1100 series.

MACID

In this section the MACID (controller number) can be configured.

MACID Source Select

The MACID parameter defines the source of the MACID (Node Address).

E1100:	
CANopen Interface\ MACID\ MACID Source Select	
B1100:	
OS\ Communication\ MACID\ MACID Source Select	
By Hex Switch S2 ³	E1100 only: The MACID is determined by the hex switch S2
By Hex Switches S1 and S2 ⁴	E1100 only: The MACID is determined by the two hex switches S1 and S2
By Parameter	The MACID is determined by parameter setting
By Dig In 1	B1100 only: The MACID is defined by DigIn1 (X13.14) at power up. 0V = ID 0, 24V = ID 1
By Dig In 2..1	B1100 only: The MACID is defined by DigIn2 .. 1 (X13.2 and X13.14) at power up. DigIn2 is the most, DigIn1 the least significant bit. (00b = ID 0, 11b = ID 3)
By Dig In 3..1	B1100 only: The MACID is defined by DigIn3 .. 1 (X13.15, X13.2 and X13.14) at power up. DigIn3 is the most, DigIn1 the least significant bit. (000b = ID 0, 111b = ID 7)
By Dig In 4..1	B1100 only: The MACID is defined by DigIn4 .. 1 (X13.3, X13.15, X13.2 and X13.14) at power up. DigIn4 is the most, DigIn1 the least significant bit. (0000b = ID 0, 1111b = ID 15)
By Dig In 5..1	B1100 only: The MACID is defined by DigIn5 .. 1 (X13.16, X13.3, X13.15, X13.2 and X13.14) at power up. DigIn5 is the most, DigIn1 the least significant bit. (00000b = ID 0, 11111b = ID 31)
By Dig In 6..1	B1100 only: The MACID is defined by DigIn6 .. 1 (X13.4, X13.16, X13.3, X13.15, X13.2 and X13.14) at power up. DigIn6 is the most, DigIn1 the least significant bit. (000000b = ID 0, 111111b = ID 63)
Parameter Value	The MACID, when "Parameter" is selected

³ Parameter not available on controllers of the B1100 series.

⁴ Parameter not available on controllers of the B1100 series.

MACID Parameter Value

Is the ID, when “By Parameter” is selected as source.

**E1100**

With the default settings, the MAC-ID and the baud rate are selected by the two rotary hex switches S1 and S2.

**B1100**

With the default settings, the MAC-ID and the baud rate are both selected by Parameter. The default values are 500kBit/s as baud rate and 63 (3Fh) for the MACID.

PDO Mapping

TxPDO 1 These parameters define the mapping of the transmit PDO1. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ TxPDO 1	
Status Word [1W]	If this Boolean parameter is set, the status word is transmitted with TxPDO1 (see variable 1D51h (E1100) / 6061h (B1100)).
State Var [1W]	If this Boolean parameter is set, the state var (high byte = state no. / low byte = sub state) is transmitted with TxPDO1 (see variable 1B62h / 6968h (B1100)).
Logged Error Code [1W]	If this Boolean parameter is set, the logged error code is transmitted with TxPDO1 (see variable 1D96h (E1100) / 6976h (B1100)).
Warn Word [1W]	If this Boolean parameter is set, the warn word (= bit coded warnings) is transmitted with TxPDO1 (see variable 1D8Eh (E1100) / 6068h (B1100)).
Demand Current [1W]	If this Boolean parameter is set, the demand current value (= motor current) is transmitted with TxPDO1 (see variable 1B93h (E1100) / E9E7h (B1100)).
Actual Position low word [1W]	If this Boolean parameter is set, the lower 16 bit of the actual position (32 bit value, see variable 1B8Dh (E1100) / F4D9h (B1100)) is transmitted with TxPDO1.
Actual Position high word [1W]	If this Boolean parameter is set, then the higher 16 bit of the actual position (32 bit value, see variable 1B8Dh (E1100) / F4D9h (B1100)) is transmitted with TxPDO1.
By UPID	This parameter can be used for free mapping of any parameter or variable to TxPDO1 (mapping through Unique Parameter ID = UPID, 0 = no mapping). The corresponding data size in TxPDO1 is either 1 word, if parameter or variable type is 16 bit or less, or 2 words, if the type is 32 bit.

TxPDO 2 These parameters define the mapping of the transmit PDO 2. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ TxPDO 2	
Motion Cmd Status [1W]	Feedback of the motion command header (toggle, etc?)
Actual Position 16 Bit [1W]	If this Boolean parameter is set, the actual motor position in 16 bit format is transmitted with TxPDO2 (see variable 1B95h (E1100) / E9A5h (B1100)).
Demand Current [1W]	If this Boolean parameter is set, the demand current value (= motor current) is transmitted with TxPDO2 (see variable 1B93h (E1100) / E9E7h (B1100)).
Demand Position 16 Bit [1W]	If this Boolean parameter is set, the demand position in 16 bit format is transmitted with TxPDO2 (position setpoint, see variable 1B94h (E1100) / E9A4h (B1100)).
By UPID	This parameter can be used for free mapping of any parameter or variable to TxPDO2 (mapping through Unique Parameter ID = UPID, 0 = no mapping). The corresponding data size in TxPDO2 is either 1 Word, if parameter or variable type is 16 bit or less, or 2 Words, if the type is 32 bit.

TxPDO 3 These parameters define the mapping of the transmit PDO 3. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ TxPDO 3	
By UPID	This parameter can be used for free mapping of any parameter or variable to TxPDO3 (mapping through Unique Parameter ID = UPID, 0 = no mapping). The corresponding data size in TxPDO3 is either 1 Word, if parameter or variable type is 16 bit or less, or 2 Words, if the type is 32 bit.

RxPDO 1 These parameters define the mapping of the receive PDO1. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ RxPDO 1	
Control Word [1W]	If this Boolean parameter is set, the control word has to be transmitted with RxPDO1 (see variable 1D52h (E1100) / 6062h (B1100)).
Motion Cmd Header + Par Byte 0..3 [3W]	Motion command interface (Header and the first 4 bytes of the command parameters).
By UPID	For free mapping, every parameter or variable can be mapped by its UPID (Unique Parameter ID). The size is either 1 word, if type is 16 bit or less, or 2 words, if the type is 32 bit.

RxPDO 2 These parameters define the mapping of the receive PDO2. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ RxPDO 2	
Motion Cmd Header + Par Byte 0..5 [4W]	Motion command interface (header and the first 6 bytes of the command parameters)
By UPID	For free mapping, every parameter or variable can be mapped by its UPID (Unique Parameter ID). The size is either 1 word, if type is 16 bit or less, or 2 words, if the type is 32 bit.

RxPDO 3 These parameters define the mapping of the receive PDO3. Four words can be mapped in total.

CANopen Interface\ PDO Mapping\ RxPDO 3	
CMD Slave Header + Par Byte 6..7 [2W]	Command interface (slave header and byte 6..7 of the parameters)
CMD Slave Header + Par Byte 6..9 [3W]	Command interface (slave header and byte 6..9 of the parameters)
CMD Slave Header + Par Byte 6..11 [4W]	Command interface (slave header and byte 6..11 of the parameters)
Direct Par X [1W] ⁵	Direct parameter channel for setting live parameters during runtime (only 16 bit parameters).
Direct Par X UPID ⁶	UPID (Unique Parameter ID) of the selected parameter
By UPID	For free mapping, every parameter or variable can be mapped by its UPID (Unique Parameter ID). The size is either 1 word, if type is 16 bit or less, or 2 words, if the type is 32 bit.

⁵ Parameter not available on controllers of the B1100 series.

⁶ Parameter not available on controllers of the B1100 series.

PDO Configuration

TxPDO 1..3 These parameters define the bus parameters of the transmit PDO1..3.

TxPDO 1..3 Enable

Selector for enabling/disabling the transmit PDO1..3.

CANopen Interface\ PDO Configuration\ TxPDO 1..3\ TxPDO 1..3 Enable	
Disable	The PDO is deactivated
Enable	The PDO is activated

Transmission Type

This defines the transmission type according DS 301. Default Value is 254 (Asynchronous with inhibit Time). Type 1 (cyclic synchronous) is supported as well.

The transmission type 250 is LinMot specific (its reserved according DS301). If transmission Type 250 is selected, the Transmit PDO is sent immediately after reception of the corresponding Receive PDO (TxPDO1 corresponds to RxPDO1). It can be used to realize a simple Poll-Request / Poll-Respond type bus structure. The "Legacy Sync WatchDog" feature can be used for monitoring (RxPDO1 takes the function of the Sync).

Inhibit Time

Defines the minimal time between two send events.

Event Time

Defines the maximal time between two send events.

RxPDO 1..3 These parameters define the bus parameters of the receive PDO1..3.

CANopen Interface\ PDO Configuration\ RxPDO 1..3	
Disable	The PDO is deactivated
Enable	The PDO is activated

NMT Error Control

Nodeguarding Protocol

Directory for configuring the nodeguarding.

Nodeguarding Enable

Enable/Disable the nodeguarding feature.

CANopen Interface\ NMT Error Control\ Nodeguarding Protocol\ Nodeguarding Enable

Disable	The Nodeguarding Protocol is deactivated.
Enable	The Nodeguarding Protocol is activated.
Guard Time	The Guard time, when Nodeguarding is activated.

Guard Time

The Guard time, when Nodeguarding is activated.

Heartbeat Protocol

These parameters configure the Heartbeat Protocol.

CANopen Interface\ NMT Error Control\ Heartbeat Protocol

Produce	Cyclic Heartbeat is produced.
Consume	Cyclic Heartbeat is consumed
Producer Time	Cycle Time for producing Heartbeat
Consumer Time	Guarding Time for consumed Heartbeat
Consumed Node ID (Master)	Node ID of the Master

Legacy Sync Watchdog

These parameters configure the legacy watchdog of the Sync Telegram. This can be used together with Heartbeat or Nodeguarding (CO firmware Version ≥ 3.8).

Watchdog Enable

Enabling/Disabling the legacy sync watchdog feature.

CANopen Interface\ NMT Error Control\ Legacy Sync Watchdog\ Watchdog Enable

Disable	The Sync Watchdog is deactivated.
Enable	The Sync Watchdog is activated.
Sync Cycle Time	The expected Sync Cycle Time.

Sync Cycle Time

The Sync cycle is monitored with $1.5 \times$ Sync Cycle Time. This means that the real expected Sync Cycle Time can be configured here.



Only one NMT Error Control Protocol should be activated.

4 Mapping of the PDO's

4.1 Mapping Table

The PDO's are mapped by default according to the following scheme:

4.1.1 Receive PDO's

R_PDO1	R_PDO2	R_PDO3	
Control Word	CMD Header	CMD Slave Header	
	Par 1	Par 4	
	Par 2	Direct Par Channel 1	
	Par 3		

Because the CMD Interface of the LinMot Controller consists of more than 8 Bytes, it's necessary to couple two PDO's together to ensure data consistency. This is done by the "CMD Slave Header". In order to execute a command both headers have to be toggled. On the slave Header only the last 4 bit are evaluated, so it's possible to simply copy the "CMD Header" from RPDO2 to the "CMD Slave Header" of RPDO3.

4.1.2 Transmit PDO's

T_PDO1	T_PDO2	T_PDO3	
Status Word	CMD Status		
Run State	Actual Position		
Error Code	Actual Current		
Warn Word	Actual SetPosition		

If the application requires it, the mapping can be completely changed by the PDO Mapping parameter settings. Many applications do not require to use all resources.

4.1.3 Default Identifier

The default identifiers (11 Bit identifier) are allocated by the following scheme:

10	9	8	7	6	5	4	3	2	1	0
Function Code				Node ID						

This results in the following table:

Object	Function Code (binary)	COB ID (hex)	Object for Comm. Parameter / Mapping
NMT	0000	00h	- / -
SYNC	0001	80h	1005h / 1006h
Emergency	0001	81h – FFh	- / -
T_PDO1	0011	181h – 1FFh	1800h
T_PDO2	0101	281h – 2FFh	1801h
T_PDO3	0111	381h – 3FFh	1802h
R_PDO1	0100	201h – 27Fh	1400h
R_PDO2	0110	301h – 37Fh	1401h
R_PDO3	1000	401h – 47Fh	1402h
T_SDO	1011	581h – 5FFh	- / -
R_SDO	1100	601h – 67Fh	- / -

In the Pre-Operational state, this can be changed with SDO downloads by the master.

5 Motor Commands

Please refer to “Usermanual Motion Control Software”

6 State Machine

Please refer to “Usermanual Motion Control Software”

7 Interface Error Codes

Please refer to “Usermanual Motion Control Software” for the Error Codes of the MC Software. The CANopen Interface has the following additional Error Codes:

Error Code Hexadecimal	Error Description
\$C1	The Controller is not compatible with CANopen
\$C2	The configured ID is not valid (switches or parameter)
\$C3	CANopen Error: Data out of Range
\$C4	CANopen Error: Invalid Command
\$C5	CANopen Error: Bus error
\$C6	CANopen Error: general Bus error
\$C7	CANopen Error: Bus error, stuff error
\$C8	CANopen Error: Bus error, form error
\$C9	CANopen Error: Bus error, ack error
\$CA	CANopen Error: Bus error, bit 1 error
\$CB	CANopen Error: Bus error, bit 0 error
\$CC	CANopen Error: Bus error, CRC error
\$CD	CANopen Error: Bus error, guard timeout
\$CE	CANopen Error: Invalid UPID configured on Direct Par 1
\$CF	CANopen Error: Invalid UPID configured on Direct Par 2
\$D0	CANopen Error: Error: Invalid ID by Hex Switch S1
\$D1	CANopen Error: Invalid Mapping in TxPDO1
\$D2	CANopen Error: Invalid Mapping in TxPDO2
\$D3	CANopen Error: Invalid Mapping in TxPDO3
\$D4	CANopen Error: Invalid Mapping in RxPDO1
\$D5	CANopen Error: Invalid Mapping in RxPDO2
\$D6	CANopen Error: Invalid Mapping in RxPDO3
\$D7	CANopen Error: Invalid UPID in TxPDO1 Mapping
\$D8	CANopen Error: Invalid UPID in TxPDO2 Mapping
\$D9	CANopen Error: Invalid UPID in TxPDO3 Mapping
\$DA	CANopen Error: Invalid UPID in RxPDO1 Mapping
\$DB	CANopen Error: Invalid UPID in RxPDO2 Mapping
\$DC	CANopen Error: Invalid UPID in RxPDO3 Mapping

8 WarnWord

Please refer to “Usermanual Motion Control Software”

9 Object Dictionary

9.1 E1100

Index	Subindex	Description	Data Type	Value
0001h–001Fh		Data Types	DEFTYPE	
0020h		Communication Parameter	DEFSTRUCT	
	0h	Number of entries	UI8	
	1h	COB-ID	UI32	
	2h	Transmission type	UI8	
	3h	Inhibit time	UI16	
	4h	Reserved	UI8	
	5h	Event timer	UI16	
1000h		Device Type	UI32	0
1001h		Error register	UI8	
1008h		Manufacturer Device Name	Visible String	4 ASCII Zeichen, welche die 4 letzten Zahlen der Artikelnummer beinhalten
1018h		Identity Object	Record	
	0h	Number of Entries	UI8	4
	1h	Vendor ID	UI32	0000 0156h
	2h	Product Code	UI32	
	3h	Revision Number	UI32	
	4h	Serial Number	UI32	
2000h–5FFFh		LinMot Parameters Index = 0x2000h + UPID	UI32	
	00h	Number of Entries		
	01h	RAM Value	SI32	RAM Value (rw)
	02h	ROM Value	SI32	ROM Value (rw)
	03h	Min Value	SI32	Minimal Value (ro)
	04h	Max Value	SI32	Maximal Value (ro)
	05h	Default Value	SI32	Default Value (ro)
	06h	RAM/ROM Write	SI32	RAM and ROM value can be written with the same value (wo)
	07h	Set ROM to default (OS)		Write anything to 0x2000h sub 7 to set all parameters of the OS to default values (wo). This command needs about 0.5s to finish.
	08h	Set ROM to default (MC)		Write anything to 0x2000h sub 8 to set all parameters of the MC Sw to default values (wo). This command needs about 2s to finish.

	09h	Set ROM to default (Interface)		Write anything to 0x2000h sub 9 to set all parameters of the CANopen Interface to default values (wo). This command needs about 0.5 s to finish.
	0Ah	Set ROM to default (Application)		Write anything to 0x2000h sub Ah to set all parameters of the Application to default values (wo)
	0Bh	Reset Controller		Write anything to 0x2000h sub Bh to reset the Controller (wo)
	20h	Start Getting UPID List		See chapter 10.3
	21h	Get Next UPID List item		See chapter 10.3
	22h	Start Getting Modified UPID List		See chapter 10.3
	23h	Get Next Modified UPID List item		See chapter 10.3
	35h	Stop MC and Application Software (for Flash access)		Write anything to 0x2000h sub 35h to stop the MC and Application SW (wo)
	36h	Start MC and Application Software		Write anything to 0x2000h sub 36h to start the MC and Application SW (wo)
	40h	Curve Service: Save to Flash		Write anything to 0x2000h sub 40h to save the curves from the RAM into the Flash ROM (wo)
	41h	Curve Service: Delete all Curves (RAM)		Write anything to 0x2000h sub 41h to Delete all Curves in the RAM (wo)
	42h	Curve Service: Poll Flash		Read anything from 0x2000h sub 42h to get the Flash state (r)
	50h	Curve Service: Add Curve		See chapter 10
	51h	Curve Service: Add Curve Info Block		See chapter 10
	52h	Curve Service: Add Curve Data		See chapter 10
	53h	Curve Service: Add Curve Data (32 Bit)		See chapter 10
	54h	Curve Service: Add Curve Info Block (32 Bit)		See chapter 10
	60h	Curve Service: Get Curve		See chapter 10
	61h	Curve Service: Get Curve Info Block		See chapter 10
	62h	Curve Service: Get Curve Data		See chapter 10
	70h	Get Error Log Entry Counter		See chapter 10.4
	71h	Get Error Log Entry Error Code		See chapter 10.4
	72h	Get Error Log Entry Time low		See chapter 10.4
	73h	Get Error Log Entry Time high		See chapter 10.4
	74h	Get Error Code Text Stringlet		See chapter 10.4

	80h	CT: Save to Flash		Write anything to 0x2000h sub 80h to save the Command Table from the RAM into the Flash ROM (w)
	80h	CT: Poll Flash		Read anything from 0x2000h sub 80h to get the Flash state (r)
	81h	CT: Delete all Entries (RAM)		Write anything to 0x2000h sub 81h to delete the complete Command Table in the RAM (wo)
	82h	CT: Delete Entry (Entry Nr.)		Write anything to 0x2000h + Entry Nr. Sub 82h to delete entry in the RAM
	83h	CT: Write Entry (Entry Nr.)		Write block size to 0x2000h + Entry Nr. Sub 83h to prepare entry in the RAM
	84h	CT: Write Entry Data		Write 2 Byte Data to 0x2000h + Entry Nr. Sub 84h, until block size has reached (the entry will be activated at this time)
	85h	CT: Get Entry (Entry Nr.)		Read the block size of 0x2000h + Entry Nr. Sub 85h.
	86h	CT: Get Entry Data		Read 2 byte data
	87h	CT: Get Entry List (Entry 0..31)		Read Bitfield (0=present)
	88h	CT: Get Entry List (Entry 32..63)		Read Bitfield (0=present)
	89h	CT: Get Entry List (Entry 64..95)		Read Bitfield (0=present)
	8Ah	CT: Get Entry List (Entry 96..127)		Read Bitfield (0=present)
	8Bh	CT: Get Entry List (Entry 128..159)		Read Bitfield (0=present)
	8Ch	CT: Get Entry List (Entry 160..191)		Read Bitfield (0=present)
	8Dh	CT: Get Entry List (Entry 192..223)		Read Bitfield (0=present)
	8Eh	CT: Get Entry List (Entry 224..255)		Read Bitfield (0=present)

9.2 B1100

Index	Subindex	Description	Data Type	Value
0001h–001Fh		Data Types	DEFTYPE	
0020h		Communication Parameter	DEFSTRUCT	
	0h	Number of entries	UI8	
	1h	COB-ID	UI32	
	2h	Transmission type	UI8	
	3h	Inhibit time	UI16	
	4h	Reserved	UI8	
	5h	Event timer	UI16	
1000h		Device Type	UI32	0
1001h		Error register	UI8	
1008h		Manufacturer Device Name	Visible String	4 ASCII Characters, which consist of the last 4 characters of the article number
1018h		Identity Object	Record	
	0h	Number of Entries	UI8	4
	1h	Vendor ID	UI32	0000 0156h for LinMot
	2h	Product Code	UI32	
	3h	Revision Number	UI32	
	4h	Serial Number	UI32	
2000h		LinMot Parameters	UI32	
	00h	Number of Entries		
	01h	RAM Value of current UPID	SI32	RAM Value (rw)
	02h	ROM Value of current UPID	SI32	ROM Value (rw)
	C0h	Update Current UPID		Write the current UPID the controller uses to get RAM and ROM values to the controller (wo)

10 Examples for controllers of the E1100 series

10.1 Write curve into the controller via CANopen

Add curve

A curve with the ID "CurveID" will be created. If a curve with the same ID already exists, an error will be generated.

Index	Subindex	Data	Result
2000h + CurveID	50h	InfoBlockSize (2 bytes) + DataBlockSize (2 bytes)	00h: No error D4h: Curve already exist

Example

LinMot MACID = 1

CuveID = 1

InfoBlockSize = 70 (0046h)

DataBlockSize = 164 (00A4h)

Index = 2001h

Subindex = 50h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Info Block Size		Data Block Size	
Data	23h	01h	20h	50h	46h	00h	A4h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	01h	20h	50h	00h	00h	00h	00h

Add Curve Info Block

Index	Subindex	Data	Result
2000h + CurveID	51h	Unused data (2 bytes) Info Block data (2 bytes)	04h: Info Block is not finished 00h: Info Block is finished D0h: Error: Info Block was already finished

Example

Index = 2001h

Subindex = 51h

Data = 0046h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data		Info Block Data	
Data	23h	01h	20h	51h	00h	00h	46h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	01h	20h	51h	00h	00h	04h	00h

Add Curve Info Block 32Bit

Index	Subindex	Data	Result
2000h + CurveID	54h	Info Block data (4 bytes)	04h: Info Block is not finished 00h: Info Block is finished D0h: Error: Info Block was already finished

Example

Index = 2001h

Subindex = 51h

Data = 0046h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Info Block Data			
Data	23h	01h	20h	51h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	01h	20h	51h	00h	00h	04h	00h

Add Curve Data

Index	Subindex	Data	Result
2000h + CurveID	52h	Unused data (2 bytes) Data Block data (2 bytes)	04h: Data Block is not finished 00h: Data Block is finished D0h: Error: Data Block was already finished

Example

Index = 2001h

Subindex = 52h

Data = 2710h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data		Data Block Data	
Data	23h	01h	20h	52h	00h	00h	10h	27h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	01h	20h	52h	00h	00h	04h	00h

Add Curve Data 32 Bit

Index	Subindex	Data	Result
2000h + CurveID	53h	Data Block data (4 bytes)	04h: Data Block is not finished 00h: Data Block is finished D0h: Error: Data Block was already finished

Example

Index = 2001h

Subindex = 53h

Data = 01312D00h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Data Block Data			
Data	23h	01h	20h	53h	00h	2Dh	31h	01h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	01h	20h	53h	00h	00h	04h	00h

10.2 Read curve from controller via CANopen

Get curve

Index	Subindex	Data	Result (4 bytes)
2000h + CurveID	60h	-	00h: Curve exists D4h: Curve does not exist

Example

CurveID = 1

Result = 00 46 1401 -> 00: Curve exists
 46: InfoBlock Size bytes
 0114: DataBlock Size bytes

Result = D4 xx xxxx -> D4: Curve does not exist

Get Curve Info Block

Index	Subindex	Data	Result (4 bytes)
2000h + CurveID	61h	-	04h: Info Block is not finished 00h: Info Block is finished D0h: Error: Info Block was already finished

Get Curve Data

Index	Subindex	Data	Result (4 bytes)
2000h + CurveID	62h	-	04h: Data Block is not finished 00h: Data Block is finished D0h: Error: Data Block was already finished

Start getting UPID List

Example

Index = 2000h
Subindex = 20h
Start UPID 1000h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Result	
Data	60h	00h	20h	20h	00h	00h	04h	00h

Index	Subindex	Data	Result
2000h	21h	Address Usage	UPID found

When the end of the list is reached the UPID FFFFh is sent.

Example

Index = 2000h
Subindex = 21h
UPID found = 1004h
Address Usage = 000Dh

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Address Usage		UPID found	
Data	43h	00h	20h	21h	0Dh	00h	04h	10h

Address Usage:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			CalculationNot used for Hash				Life Parameter					ROM Write	ROM Read	RAM Write	RAM Read

The commands for getting the modified UPID List are used the same way.

10.4 Read the Error Log from the Controller

Get Error Log Entry Counter

Index	Subindex	Data	Result
2000h	70h	-	Number of Logged Errors Number of Occurred Errors

Example

Index = 2000h

Subindex = 70h

Number of Logged Errors = 0015h

Number of Occurred Errors = 0034h

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	00h	20h	70h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Nr. of Logged Err		Nr. Of Occurred Err	
Data	43h	00h	20h	70h	15h	00h	34h	00h

Get Error Log Entry Error Code

Index	Subindex	Data	Result
2000h + Entry Nr.	71h	-	Error Code

Example

Index = 2005h

Subindex = 71h

Error Code of entry 5 = 64h (Cfg. Err: No Motor defined)

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	05h	20h	71h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Unused Data		Error Code	
Data	43h	05h	20h	71h	00h	00h	64h	00h

Get Error Log Entry Time Low

Index	Subindex	Data	Result
2000h + Entry Nr.	72h	-	Time Low (milliseconds)

Example

Index = 2005h

Subindex = 72h

Time Low of entry 5 = 28C1h (=10433ms=10.433s)

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	05h	20h	72h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Time Low		Time Mid Low	
Data	43h	05h	20h	72h	C1h	28h	00h	00h

Get Error Log Entry Time High

Index	Subindex	Data	Result
2000h + Entry Nr.	73h	-	Time High (hours)

Example

Index = 2005h

Subindex = 73h

Time High of entry 5 = 0398h (=920 hours)

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	05h	20h	73h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:

		Index		Subindex	Time Mid High		Time High	
Data	43h	05h	20h	73h	98h	03h	00h	00h

The Time of an entry consists of 32Bit hours and 32Bit milliseconds.

Get Error Code Text Stringlet

Index	Subindex	Data	Result
2000h + Error Code.	74h + (Stringlet Nr. 0..7)	-	4 Bytes of Error Code Text

Example

Index = 2064h (Error Code 64h = „Cfg Err: No Motor Defined“)

Subindex = 74h

Character 0..3 = 43 66 67 20 = “Cfg “

CAN Telegram (8 Byte Data), COB-ID 601, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	64h	20h	74h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581, LinMot Controller -> PLC:


		Index		Subindex	Char 0	Char 1	Char 2	Char 3
Data	43h	64h	20h	74h	43h	66h	67h	20h

The Time of an entry consists of 32Bit hours and 32Bit milliseconds.

11 Examples for controllers of the B1100 series

Read or Write the value of a UPID of the controller via CANopen

Reading or writing the value of a UPID from/to the controller, has to be performed in two separate steps. First the UPID on which to operate (i.e. read or write) has to be sent to the controller via an SDO-command (index 2000h and sub index C0h). This UPID will be referred to as the actual UPID from here on. After this is done the value of the actual UPID can be read or written by other SDO-Commands (index 2000h and sub indices 01h and 02h).



11.1 Read the value of a UPID from a B1100 controller

1. Write the actual UPID which the controller uses

Index	Subindex	Data	Unused
2000h	C0h	UPID	-

Example

Index = 2000h

Subindex = C0h

UPID = E9E7h (UPID of the Demand Current)

CAN Telegram (8 Byte Data), COB-ID 601h, PLC -> LinMot Controller:

Data	Index	Subindex	UPID	Unused Data
23h	00h	20h	C0h	E7h E9h 00h 00h

Response: (8 Byte Data), COB-ID 581h, LinMot Controller -> PLC:

Data	Index	Subindex	Unused Data
60h	00h	20h	C0h 00h 00h 00h 00h

2. Read the value of the actual UPID from the controller

Index	Subindex	Result
2000h	01h	Value of the actual UPID

Example

Index = 2000h

Subindex = 01h (Value is read from the RAM)

CAN Telegram (8 Byte Data), COB-ID 601h, PLC -> LinMot Controller:

		Index		Subindex	Unused Data			
Data	40h	00h	20h	01h	00h	00h	00h	00h

Response: (8 Byte Data), COB-ID 581h, LinMot Controller -> PLC:

		Index		Subindex	UPID Parameter Value			
Data	43h	00h	20h	01h	DCh	FEh	FFh	FFh

Returned value of the Demand Current = FFFFFFFEDCh
 = -292 Dec. (Scale 0.001 A)
 = -0.292 A

11.2 Write the value of a UPID to a B1100 controller**1. Write the actual UPID which the controller uses**

Index	Subindex	Data	Unused
2000h	C0h	UPID	-

Example

Index = 2000h

Subindex = C0h

UPID = E19Ch (UPID of the Maximal Current)

CAN Telegram (8 Byte Data), COB-ID 601h, PLC -> LinMot Controller:

		Index		Subindex	UPID		Unused Data	
Data	23h	00h	20h	C0h	9Ch	E1h	00h	00h

Response: (8 Byte Data), COB-ID 581h, LinMot Controller -> PLC:

		Index		Subindex	Unused Data			
Data	60h	00h	20h	C0h	00h	00h	00h	00h

2. Write the desired value of the actual UPID to the controller

Index	Subindex	Data
2000h	01h	Desired value of the actual UPID

Example

Index = 2000h

Subindex = 01h (The value is written to the RAM)

Desired value of the Maximal Current = 0BB8h
 = 3000 Dec. (Scale 0.001 A)
 = 3 A

CAN Telegram (8 Byte Data), COB-ID 601h, PLC -> LinMot Controller:

		Index		Subindex	Desired UPID Parameter Value			
Data	23h	00h	20h	01h	B8h	0Bh	00h	00h

Response: (8 Byte Data), COB-ID 581h, LinMot Controller -> PLC:

		Index		Subindex	Unused Data			
Data	60h	00h	20h	01h	00h	00h	00h	00h

12 Reset Parameters to default values on E1100

There are three options to reset the parameters of a LinMot E1100 controller to default values:

- 1) By manipulating the two rotary hex switches:
 - Power Off the controller
 - Set the switches to FF
 - Power On the controller
 - Set the switches to 00
 - Wait for 10 s
 - Power Off the controller
- 2) By writing Index 0x2000h subindex 7h, 8h, 9h, Ah of the Object dictionary.
After changing the ROM values, a Reset should be performed either by a NMT Reset command or by Power OFF and ON the controller.
- 3) Reinstall the firmware will always reset the parameters to default values

13 Example for setting up a motion command

The following example shows the homing procedure and execution of a motion command via CANopen:

The PDO mapping is default:

R_PDO1	R_PDO2	R_PDO3
Control Word	CMD Header	CMD Slave Header
	Par Byte 0...1	Par Byte 6...7
	Par Byte 2...3	
	Par Byte 4...5	

1) Homing (Control Word = 083Fh)

R_PDO1

CAN Telegram (2 Byte Data), COB-ID 201h, PLC -> LinMot Controller:

Byte Nr.	0	1	2	3	4	5	6	7
Data	3Fh	08h	xx	xx	xx	xx	xx	xx

2) Enter Operational State (Control Word = 003Fh)

R_PDO1

CAN Telegram (2 Byte Data), COB-ID 201h, PLC -> LinMot Controller:

Byte Nr.	0	1	2	3	4	5	6	7
Data	3Fh	00h	xx	xx	xx	xx	xx	xx

3) Execute Motion Command : VAI 16Bit Go To Pos (090xh)

CMD Header	→		0901h
CMD Slave Header	→		0901h
Par Byte 0...1	→	Target Position :	50mm 01F4h
Par Byte 2...3	→	Maximal Velocity :	1m/s 03E8h
Par Byte 4...5	→	Acceleration :	10m/s ² 0064h
Par Byte 6...7	→	Deceleration :	10m/s ² 0064h

R_PDO2

CAN Telegram (8 Byte Data), COB-ID 301h, PLC -> LinMot Controller:

Byte Nr.	0	1	2	3	4	5	6	7
Data	01h	09h	F4h	01h	E8h	03h	64h	00h

R_PDO3

CAN Telegram (4 Byte Data), COB-ID 401h, PLC -> LinMot Controller:

Byte Nr.	0	1	2	3	4	5	6	7
Data	01h	09h	64h	00h	xx	xx	xx	xx

As it appears with LinMot-Talk1100 after «Read Command» in the Control Panel :

Motion Command Interface

Enable Manual Override: ☐

-10 mm

-1 mm

+1 mm

+10 mm

Command Category:

All

Command Type: VAI 16Bit Go To Pos (090xh)



Count Nibble (Toggle Bits):

1h



Auto Increment Count Nibble

Name	Offs.	Description	Scaled Value	Int. Value (Dec)	Int. Value (Hex)
Header	0	090xh: VAI 16Bit Go To Pos	2305	2305	0901h
1. Par	2	Target Position	0 mm	0	0000h
2. Par	4	Maximal Velocity	1 m/s	1000	03E8h
3. Par	6	Acceleration	10 m/s ²	100	0064h
4. Par	8	Deceleration	10 m/s ²	100	0064h

Read Command

Send Command

14 Quick Start Guide for advanced users

The aim of this chapter is to help users who are already familiar with the LinMot-Controllers and the LinMot-Talk 1100 Software with the setup which is needed to get the controller up and running in CANopen-Network.

14.1 Hardware-Setup

Set up the hardware as described in chapter 2 of this manual.

14.2 Configuration of the controller

The default value for the MACID (Node ID) is « 1 » for E1100 controllers and « 63 » for B1100 controllers. The default baudrate is «500 kbaud».

If different settings are to be used, those parameters have to be properly configured first. This has to be done with the LinMot-Talk1100 software.

14.3 Starting the device

The CANopen Network Management (NMT) protocol allows starting of devices with a single NMT-Telegram :

CAN Telegram (2 Byte Data), COB-ID 000, PLC -> LinMot Controller:

Byte Nr.	0	1	2	3	4	5	6	7
Data	01h	MACID	xx	xx	xx	xx	xx	xx

The first byte identifies the Start Remote Node command, the second byte is the MACID of the controller. If 0x00 is used as the MACID, all Nodes in the network are started. This command puts the controller in operational mode.

After this all SDO's and PDO's can be used.

The default configuration for the transmission type of the PDO's is 254 (Asynchronous transmission with inhibit Time).

15 Contact Addresses

SWITZERLAND

NTI AG

Haerdlistr. 15
CH-8957 Spreitenbach

Sales and Administration:

+41-(0)56-419 91 91
office@linmot.com

Tech. Support:

+41-(0)56-544 71 00
support@linmot.com

Tech. Support (Skype) :

skype:support.linmot

Fax:

+41-(0)56-419 91 92

Web:

<http://www.linmot.com/>

USA

LinMot, Inc.

5750 Townline Road
Elkhorn, WI 53121

Sales and Administration:

877-546-3270
262-743-2555

Tech. Support:

877-804-0718
262-743-1284

Fax:

800-463-8708
262-723-6688

E-Mail:

us-sales@linmot.com

Web:

<http://www.linmot-usa.com/>

Please visit <http://www.linmot.com/> to find the distribution near you.

Smart solutions are...

